



X1-Lite-LV

8 kW / 10 kW / 12 kW

User Manual

Version 2.0



www.solaxpower.com

STATEMENT

Copyright

Copyright © SolaX Power Network Technology (Zhejiang) Co., Ltd. All rights reserved.

No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means without the prior written permission of SolaX Power Network Technology (Zhejiang) Co., Ltd.

Trademarks

solution and other symbol or design (brand name, logo) that distinguishes the products or services offered by SolaX has been trademark protected. Any unauthorized use of the above stated trademark may infringe the trademark right.

Notice

Please note that certain products, features, and services mentioned in this document may not be within the scope of your purchase or usage. Unless otherwise specified in the contract, the contents, information, and recommendations presented in this document are provided "as is" by SolaX. We do not provide any warranties, guarantees, or representations, whether express or implied.

The content of the documents is reviewed and updated as needed. However, occasional discrepancies may occur. SolaX retains the right to make improvements or changes in the product(s) and the program(s) described in this manual at any time without prior notice.

The images included in this document are solely for illustrative purposes and may differ based on the specific product models.

For more detailed information, kindly visit the website of SolaX Power Network Technology (Zhejiang) Co., Ltd. at www.solaxpower.com.

SolaX retains all rights for the final explanation.

Scope of Validity

This manual is an integral part of X1-Lite-LV series inverter. It describes the transportation, storage, installation, electrical connection, commissioning, maintenance and troubleshooting of the product. Please read it carefully before operating.

This manual is valid for the following inverter models:

- X1-Lite-8K-LV
- X1-Lite-10K-LV
- X1-Lite-12K-LV

Model description



Item	Meaning	Description	
1	Product family name	"X1-Lite": energy storage series inverter that ne supports grid connection of photovoltaic system;	
2	Power "8K": rated output power of 8 kW.		
3 Low voltage "LV" means the inverter should pair with lo battery voltage battery.		"LV" means the inverter should pair with low voltage battery.	

Target Group

The installation, maintenance and grid-related setting can only be performed by qualified personnel who:

- Are licensed and/or satisfy state and local regulations.
- Have good knowledge of this manual and other related documents.

Conventions

The symbols that may be found in this manual are defined as follows.

Symbol	Description	
Anger 🕂	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.	
	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.	
CAUTION! Indicates a hazardous situation which, if not avoide could result in minor or moderate injury.		
NOTICE!	Provides tips for the optimal operation of the product.	

Change History

Version 2.0 (2025-01-13)

Updated "2.7 Working Mode" (Updated the descriptions about working modes)

Updated "5.1.1 Environment Requirement" (Updated the contents)

Updated "10 Operation on LCD" (Updated the descriptions of the LED indicators and the setting contents)

Updated "12.2 Troubleshooting" (Updated the troubleshooting list)

Added "15 Appendix" (Added contents about parallel function and generator)

Version 1.0 (2024-07-20)

Updated "14 Technical Data"

Version 0.0 (2024-06-20)

Initial release

Table of Contents

1 Saf		afety1		
	1.1	Gener	ral Safety	1
			Instructions of PV, Inverter, Grid and Battery	
		1.2.1		
		1.2.2	Safety Instructions of Inverter	
		1.2.3	Safety Instructions of Utility Grid	
		1.2.4	Safety Instructions of Battery	
2	Pro	oduct	Overview	
	2.1	Produ	Ict Introduction	5
	2.2	Appea	arance	5
	2.3	Suppo	orted Power Grid	6
	2.4	Symb	ols on the Label and Inverter	7
	2.5	Worki	ng Principle	8
		2.5.1	Circuit Diagram	8
		2.5.2	Application Schemes	9
	2.6	Worki	ng State	9
	2.7	Worki	ng Mode	
		2.7.1	SUB Mode (Pakistan)	
		2.7.2	SBU Mode (Pakistan)	
		2.7.3	MKS/EPS Mode (Pakistan)	
		2.7.4	Force Time Use Mode (Pakistan)	13
		2.7.5	Back Up Mode (Other Countries)	14
		2.7.6	Self Consumption Mode (Other Countries)	15
		2.7.7	Force Time Use Mode (Other Countries)	
3	Sys	stem (Overview	
4	Tra	nspor	rtation and Storage	20
5	Pre	eparat	ion before Installation	21
	5.1	Select	tion of Installation Location	21
		5.1.1	Environment Requirement	21
		5.1.2	Installation Carrier Requirement	23
		5.1.3	Clearance Requirement	23
	5.2	Tools	Requirement	25
	5.3	Additi	onally Required Materials	26

6	Unpacking and Inspection	28
	6.1 Unpacking	
	6.2 Scope of Delivery	29
7	Mechanical Installation	
	7.1 Dimensions for mounting	
	7.2 Installation procedures	
8	Electrical Connection	
	8.1 Terminals of Inverter	
	8.2 PE Connection	
	8.3 EPS, GEN and GRID Connection	40
	8.4 PV Connection	47
	8.5 Battery Power Cable Connection	51
	8.6 COM Communication Connection	57
	8.6.1 Pin Assignment of COM Terminal	57
	8.6.2 DI/COM Connection	58
	8.6.3 DO Connection	59
	8.6.4 BMS Communication Connection	59
	8.6.5 DRM Connection (Applicable to AS/NZS 4777.2)	59
	8.6.6 Meter/CT Connection	60
	8.6.7 Parallel Connection	63
	8.6.8 Wiring procedure of COM Communication Connection	64
	8.7 Monitoring Connection	72
9	System Commissioning	75
	9.1 Checking before Power-on	75
	9.2 Powering on the System	75
10	Operation on LCD	77
	10.1 Introduction of Control Panel	77
	10.2 Introduction of Menu Interface	79
	10.3 Work Mode	82
	10.4 Export Control	
	10.5 Battery Setting	
	10.6 About	
	10.7 Smart Load	
	10.8 Setting	90
	10.8.1 Basic Setting	90
	10.8.2 Advanced Setting	92
	10.9 History Errors	98

	10.10 Parallel Setting	98
11	Operation on SolaX App and Web	99
	11.1 Introduction of SolaXCloud	99
	11.2 Operation Guide on SolaXCloud App	99
	11.2.1 Downloading and Installing App	99
	11.2.2 Operations on App	99
	11.3 Operations on SolaXCloud Webpage	99
12	Troubleshooting and Maintenance	100
	12.1 Power off	100
	12.2 Troubleshooting	100
	12.3 Maintenance	111
	12.3.1 Maintenance routines	111
	12.3.2 Upgrading Firmware	112
13	Decommissioning	114
	13.1 Disassembling the Inverter	114
	13.2 Packing the Inverter	116
	13.3 Disposing of the Inverter	116
14	Technical Data	117
15	Appendix	120
	15.1 Application of Parallel Function	120
	15.1.1 Introduction of Parallel Application	120
	15.1.2 Notice for Parallel Application	120
	15.1.3 System Wiring Diagram	121
	15.1.4 System Wiring Procedure	122
	15.1.5 Settings for Parallel Connection	124
	15.2 Application of Generator	125
	15.2.1 Introduction of Generator Application	125
	15.2.2 Notice for Generator Application	125
	15.2.3 Dry Contact Mode	126

1.1 General Safety

The series inverter has been meticulously designed and thoroughly tested to comply with the relevant state and international safety standards. Nevertheless, like all electrical and electronic equipment, safety precautions must be observed and followed during the installation of the inverter to minimize the risk of personal injury and ensure a safe installation.

Please thoroughly read, comprehend, and strictly adhere to the comprehensive instructions provided in the user manual and any other relevant regulations prior to the installation of the inverter. The safety instructions in this document serve as supplementary guidelines to local laws and regulations.

SolaX shall not be liable for any consequences resulting from the violation of the storage, transportation, installation, and operation regulations outlined in this document. Such consequences include, but are not limited to:

- Inverter damage caused by force majeure events, such as earthquakes, floods, thunderstorms, lightning, fire hazards, volcanic eruptions, and similar events.
- Inverter damage due to human causes.
- Usage or operation of the inverter in violation of local policies or regulations.
- Failure to comply with the operation instructions and safety precautions provided with the product and in this document.
- Improper installation or usage of the inverter in unsuitable environmental or electrical conditions.
- Unauthorized modifications to the product or software.
- Inverter damage occurring during transportation by the customer.
- Storage conditions that do not meet the requirements specified in this document.
- Installation and commissioning performed by unauthorized personnel who lack the necessary licenses or do not comply with state and local regulations.

1.2 Safety Instructions of PV, Inverter, Grid and Battery

Save these important safety instructions. Failure to follow these safety instructions may result in damage to the inverter and injury or even loss of life.

1.2.1 Safety Instructions of PV

\Lambda DANGER!

Potential risk of lethal electric shock associated with the photovoltaic (PV) system

- Exposure to sunlight can result in the generation of high DC voltage by PV modules, which can lead to electric shock causing severe injuries or even death.
- Never touch the positive or negative poles of the PV connecting device, and avoid touching both poles simultaneously.
- Do not ground the positive or negative poles of the PV modules.
- Only qualified personnel can perform the wiring of the PV modules.

\Lambda WARNING!

- Overvoltage protection with surge arresters should be provided when the PV system is installed. The inverter is fitted with SPDs on both PV input side and MAINS side.
- Please consult professionals before installing SPDs.

🕂 WARNING!

• Make sure that the input DC voltage does not exceed the maximum DC input voltage specified for the inverter. Overvoltage can cause irreversible damage to the inverter, and such damage is not covered by the warranty.

\Lambda WARNING!

• A photovoltaic module used on the inverter must have an IEC61730 class A rating, and the total open circuit voltage of the photovoltaic string / array is lower than the maximum rated DC input voltage of the inverter. Any damage caused by photovoltaic overvoltage is not covered by warranty.

1.2.2 Safety Instructions of Inverter

\Lambda DANGER!

Potential risk of lethal electric shock associated with the inverter

- Only operate the inverter if it is in a technically faultless condition. Operating a faulty inverter may lead to electric shock or fire.
- Unauthorized opening of the upper cover will void the warranty and can result in lethal danger or serious injury due to electric shock.
- Make sure that the inverter is reliably grounded before any operation to prevent the risk of electric shock causing lethal danger or serious injury.
- Only qualified personnel can perform the installation, wiring, maintenance of the inverter by following this document and the related regulations.

WARNING!

- During operation, avoid touching any parts of the inverter other than the DC switch and LCD panel (if any).
- Never connect or disconnect the AC and DC connector while the inverter is running.
- Prior to conducting any maintenance, turn off the AC and DC power and disconnect them from the inverter. Wait for 5 minutes to fully discharge the energy.

\Lambda WARNING!

- The inverter can not be operated when it is running. Radiation may be harmful to health! Do not stay for a long time and keep at least 20 cm away from the inverter.
- After the inverter and power grid cut off the PV power supply, there will be a certain amount of residual voltage in a short time, be cautious or it may lead to serious personal injury and even high risk of death. Use a multimeter (impedance at least 1 MΩ) to measure the voltage between the UDC and the UDC to ensure that the inverter port is discharged below the safe voltage before starting operation (35 VDC).

WARNING!

Potential danger of scalding due to the hot enclosure of the inverter

• Avoid touching the inverter while it is running, as it becomes hot during operation and may cause personal injuries.

🕂 WARNING!

• Use insulated tools when installing the device, and always wear personal protective equipment during installation and maintenance.

- Make sure that children are supervised to prevent them from playing with the inverter.
- Pay attention to the weight of the inverter and handle it properly to avoid personal injuries.

NOTICE!

- The inverter has an integrated Type-B Residual Current Monitoring Unit (RCMU). If an external Residual Current Device (RCD) is required by local regulations, verify the type of RCD required. It is recommended to use a Type-A RCD with a rating of 300 mA unless a lower value is required by the specific local electric codes. When required by local regulations, the use of an RCD type B is permitted.
- Keep all product labels and the nameplate on the inverter clearly visible and wellmaintained.

1.2.3 Safety Instructions of Utility Grid

NOTICE!

• Only connect the inverter to the grid with the permission of the local utility grid company.

1.2.4 Safety Instructions of Battery

🔨 warning!

- SolaX assumes no responsibility for any problems arising from the use of third-party lithium batteries connected as lead-acid batteries.
- Prohibit the use of SolaX lithium battery in Lead-acid mode. Any consequences arising from the use of lead-acid mode shall be borne by users themselves, and SolaX will not provide warranty!

\Lambda warning!

• When handling the battery, carefully follow all safety instructions provided in the battery manual. The battery used with the inverter must meet the specified requirements of the series inverter.

NOTICE!

• This inverter should pair with low voltage battery, for the specific parameters such as battery type, nominal voltage and nominal capacity etc., please refer to Battery Data. Refer to the matching battery specification for details.

4

2.1 Product Introduction

The X1-Lite-LV series inverter is an energy storage PV grid-connected inverter. It supports various intelligent solutions to achieve efficient and economical energy utilization.

2.2 Appearance




Figure 2-1 Appearance

Table 2-1	Description	of appearance
-----------	-------------	---------------

Item Description	
Nameplate	Nameplate clearly identifies the device type, serial number, specific DC / AC parameters, certification, etc.
LCD panel	Including screen, indicators and keys. Screen displays the information; indicators indicate the status of inverter. Keys are used to perform the parameter setting.
DC switch	Connect or disconnect the PV input.
Electrical connection area	Including PV terminals, battery terminals, GEN, GRID and EPS terminals, communication terminals, etc.

2.3 Supported Power Grid

There are different ways of wiring for different grid systems. TT / TN-S / TN-C-S are shown as below:




Figure 2-2 Supported power grid-TT




Figure 2-3 Supported power grid-TN-S




Figure 2-4 Supported power grid-TN-C-S

2.4 Symbols on the Label and Inverter


Table 2-2 Description of symbols


Symbol	Description
CE	CE mark. The inverter complies with the requirements of the applicable CE guidelines.
TÜVRhenland CERTFHED	TUV certified.
	Additional grounding point.
	Beware of hot surface. Do not touch a running inverter, as the inverter becomes hot during operation!
4	Risk of electric shock. High voltage exists after the inverter is powered on!
	Risk of danger. Potential hazards exist after the inverter is powered on!
	Read the enclosed documentations.
X	Do not dispose of the inverter together with household waste.
	Do not operate this inverter until it is isolated from battery, mains and on- site PV generation source.
	Danger of high voltage. Do not touch live parts for 5 minutes after disconnection from the power sources.

2.5 Working Principle


2.5.1 Circuit Diagram

The inverter is equipped with multi-channel MPPT for DC input to ensure maximum power even under different photovoltaic input conditions. The inverter unit converts direct current into alternating current that meets the requirements of the power grid and feeds it into the power grid. The principle design of inverter is shown in the figure below:









2.5.2 Application Schemes

Figure 2-6 Partial home backup for most countries

2.6 Working State

The series inverter has INIT, IDLE, START, RUN and STOP state.

Table 2-3 Description of working state

State	Description
INIT	 The inverter is checking for the initialization information such as the model and country, the conditions to be met in order to enter IDLE state.
IDLE	 The inverter is doing some preparations to enter START state, such as checking relays.
START	 The inverter is being started and ready for on-grid or off-grid operation.
RUN	• The inverter is working in on-grid or off-grid state.
STOP	Users power off the inverter or fault occurs to the inverter.

2.7 Working Mode

There are different work modes of the inverter based on different needs.

Applicable areas	Work modes
Pakistan	SUB mode, SBU mode, MKS/EPS mode and Force time use mode
Countries other than Pakistan (including Vietnam, India, South Africa, etc.)	Back up mode, Self consumption mode, and Force time use mode

For how to set the working mode, please refer to "10.3 Work Mode".

2.7.1 SUB Mode (Pakistan)

SUB mode is applicable to Pakistan. This mode uses the energy storage system as a backup power source and is suitable for applications with frequent power outages or wish to feed excess electricity generated by PV into the grid.

Battery state	Battery Charge Source	Power Supply Situation	
	PV Only	 PV → load > battery > grid PV prioritizes supplying power to the load. If PV is insufficient, the grid supplies power to the load. If the PV output exceeds the load demand, the surplus energy is first used to charge the battery. Once the battery is fully charged, the excess energy is fed into the grid according to the Export Control settings. For specific settings, please refer to "10.4 Export Control". In off-grid situation, both PV and the battery supply power to the load. 	
The battery	PV Then Utility	PV is available: PV → load > battery > grid • Consistent with the PV Only charging situation.	
is not fully charged		 PV is not available: grid → load+battery The grid supplies power to the load and draws electricity from the grid to charge the battery based on the Max Utility Charge Current. 	
	PV and Utility	 PV → load > battery > grid, and grid → battery PV is prioritized for the load, with excess used to charge the battery. Simultaneously, power is drawn from the grid to charge the battery based on the Max Utility Charge Current. After the battery is fully charged, surplus energy is either fed into the grid or curtailed according to Export Control settings. For specific settings, please refer to "10.4 Export Control". 	

Table 2-4 Description of SUB mode

2.7.2 SBU Mode (Pakistan)

This mode is applicable to Pakistan and suitable for applications where electricity prices are high and PV cannot be fed into the grid. PV is prioritized for loads, and excess power is stored in the battery for later use. This mode is ideal for customers with low daytime electricity consumption and higher nighttime electricity consumption. **No Export** is set by default to disallow power feed-in to grid for this mode.

Battery state	Battery Charging And Discharging Situation	Power Supply Situation
	PV Only charging	 PV → battery, grid → load PV charges the battery, and the load is supplied by the grid.
	PV Then Utility charging DC	 PV is available: PV → battery > load PV prioritizes supplying power to the battery. If the PV output exceeds the battery demand, the surplus energy is first used to supply the load.
BAT< Return to Utility Voltage/SOC		 PV is not available: grid → load+battery The grid supplies power to the load and charge the battery based on the Max Utility Charge Current. For specific settings, please refer to "10.4 Export Control".
	PV and Utility charging	 PV+grid → battery, grid → load All electricity generated by the PV is used to charge the battery, and concurrently, power is drawn from the grid to charge the battery based on the Max Utility Charge Current. For specific settings, please refer to "10.4 Export Control".
BAT> Return to Battery SOC (Lithium battery)	Battery discharge	 PV+battery → load PV prioritizes supplying power to the load. If the PV is insufficient, the battery supplies power to the load until the battery voltage/SOC is less than the Return to Utility SOC.

Table 2-5 Description of SBU mode

Battery state	Battery Charging And Discharging Situation	Power Supply Situation
BAT> Return to Battery Voltage (Lead acid battery)	With Charge to Full on, battery first charge then discharge	 First PV/PV+grid/grid → battery, then PV +battery → load The battery will continued to be charged by the charging source until it reaches the float voltage, then the inverter will work off-grid two minutes later (PV is priority to supply power to the load. If the PV is insufficient, the battery supplies power to the load until the battery voltage is less than the Return to Utility Voltage).
	With Charge to Full off, battery discharge	 PV+battery → load PV prioritizes supplying power to the load. If the PV is insufficient, the battery supplies power to the load until the battery voltage is less than the Return to Utility Voltage.

2.7.3 MKS/EPS Mode (Pakistan)

This mode is applicable to Pakistan and suitable for customers who have higher electricity consumption during the day and lower consumption at night.

When PV is available, the working logic will switch based on settings for **Return to SUB Mode** and **Return to SBU Mode**. At night when PV is unavailable, this mode is basically the same as the SUB mode, with the battery only charging and not discharging, which prevents the battery from being depleted.

PV state	Battery state	Inverter working state
	Battery voltage/SOC > Return to SBU Mode	The inverter works in basically same as the SBU mode.
PV is available	Battery voltage/SOC < Return to SUB Mode	The inverter works in basically same as the SUB mode, and charges the battery with the selected charging source (PV prioritizes charging the battery), and switches to basically same as the SBU mode when the battery voltage/SOC reaches Return to SBU Mode .
PV is unavailable	/	The inverter works in basically same as the SUB mode.

Table 2-6 Descrip	tion of MKS/EP	Smode
-------------------	----------------	-------

2.7.4 Force Time Use Mode (Pakistan)

This mode is suitable for application with peak and valley price difference. When the price of electricity is high, the battery is discharged to supply the load, and when the price of electricity is low, the battery is charged from PV or the grid to reach full capacity.

Time Period	Battery Charging And Discharging Situation	Power Supply Situation
	PV Only charging	 PV → battery, grid → load PV charges the battery, and the load is supplied by the grid.
Charge Period	PV Then Grid charging	 PV+grid → battery+load PV prioritizes charging the battery, if the PV is insufficient, electricity is drawn from the grid to charge the battery. The load is supplied by the grid.
	PV and Grid charging	 PV+grid → battery+load All electricity generated by the PV is used to charge the battery, and concurrently, power is drawn from the grid to charge the battery based on the Max Utility Charge Current. For specific settings, please refer to "10.4 Export Control".
Home Load Removed From Utility Time Periods	Battery discharge	 Battery+grid → load The battery discharges to supply the load until the battery voltage is less than the Battery Stop Discharge Voltage or SOC, after which the load will be supplied by the grid.
Outside of peak- valley scheduled time periods	The battery charges acc battery charging source	cording to the priority settings of the mode.

Table 2-7 Description of Force Time Use mode

2.7.5 Back Up Mode (Other Countries)

Back up mode is applicable to countries other than Pakistan.

This mode uses the energy storage system as a backup power source and is suitable for applications with frequent power outages or wish to feed excess electricity generated by PV into the grid.

Battery state	Battery Charge Source	Power Supply Situation
	PV Only	 PV → load > battery > grid PV prioritizes supplying power to the load. If PV is insufficient, the grid supplies power to the load. If the PV output exceeds the load demand, the surplus energy is first used to charge the battery. Once the battery is fully charged, the excess energy is fed into the grid according to the Export Control settings. For specific settings, please refer to "10.4 Export Control". In off-grid situation, both PV and the battery supply power to the load.
The battery		 PV is available: PV → load > battery > grid Consistent with the PV Only charging situation.
is not fully charged PV Then Util	PV Then Utility	 PV is not available: grid → load+battery The grid supplies power to the load and draws electricity from the grid to charge the battery based on the Max Utility Charge Current.
	PV and Utility	 PV → load > battery > grid and grid → battery PV is prioritized for the load, with excess used to charge the battery. Simultaneously, power is drawn from the grid to charge the battery based on the Max Utility Charge Current. After the battery is fully charged, surplus energy is either fed into the grid or curtailed according to Export Control settings. For specific settings, please refer to "10.4 Export Control".

Table 2-8 Description of Back Up mode

2.7.6 Self Consumption Mode (Other Countries)

This mode is applicable to countries other than Pakistan and suitable for applications where electricity prices are high and PV cannot be fed into the grid. PV is prioritized for loads, and excess power is stored in the battery for later use. This mode is ideal for customers with low daytime electricity consumption and higher nighttime electricity consumption. **No Export** is set by default to disallow power feed-in to grid for this mode.

There are three options under this mode, i.e. **Self Comp**, **Battery First** and **Load First**, among which the working logic is slightly different.

- Self Comp		
Battery state	Battery Charging And Discharging Situation	Power Supply Situation
	PV Only charging	 PV → battery, grid → load PV charges the battery, and the load is supplied by the grid.
BAT< Return to Utility Voltage/SOC	D) / These likility	 PV is available: PV → battery > load PV prioritizes supplying power to the battery. If the PV output exceeds the battery demand, the surplus energy is first used to supply the load.
	PV Then Utility charging	 PV is not available: grid → load+battery The grid supplies power to the load and charge the battery based on the Max Utility Charge Current. For specific settings, please refer to "10.4 Export Control".
	PV and Utility charging	 PV+grid → battery, grid → load All electricity generated by the PV is used to charge the battery, and concurrently, power is drawn from the grid to charge the battery based on the Max Utility Charge Current. For specific settings, please refer to "10.4 Export Control".
BAT>Return to Battery Voltage/ SOC	Battery discharge	 PV+battery → load PV prioritizes supplying power to the load. If the PV is insufficient, the battery supplies power to the load until the battery voltage/SOC is less than the Return to Utility Voltage/SOC.

Table 2-9 Description of Self Consumption mode - Self Comp

Option	PV State	Power Supply Situation
	PV is sufficient	 PV → load > battery PV prioritizes supplying power to the load. If the PV output exceeds the load demand, the surplus energy is used to charge the battery.
Load First	PV is insufficient	 PV+battery → load Both PV and battery supply power to the load. When the battery voltage/SOC < Return to Utility Voltage/SOC, the battery will stop discharging.
	PV > battery maximum charging power	 PV → battery > load PV prioritizes supplying power to the battery. If the PV output exceeds the battery demand, the surplus energy is used to supply the load.
Battery First	PV < battery maximum charging power	 If the charge source is selected as PV Only or PV then Utility, the battery is supplied solely by PV (PV → battery). If the charge source is selected as PV and Utility, the battery is supplied by both PV and grid (PV+grid → battery).
	PV is unavailable	 If the charge source is selected as PV Only, the battery won't be charged. If the charge source is selected as PV then Utility or PV and Utility, the battery is supplied by the grid (grid → battery).

Table 2-10 Description of Self Consumption mode - Load First and Battery First

2.7.7 Force Time Use Mode (Other Countries)

This mode is suitable for application with peak and valley price difference. When the price of electricity is high, the battery is discharged to supply the load, and when the price of electricity is low, the battery is charged from PV or the grid to reach full capacity*.

Time Period	Battery Charging And Discharging Situation	Power Supply Situation
	PV Only charging	 PV → battery, grid → load PV charges the battery, and the load is supplied by the grid.
Charge Period	PV Then Grid charging	 PV+grid → battery+load PV prioritizes charging the battery, if the PV is insufficient, electricity is drawn from the grid to charge the battery. The load is supplied by the grid.
	PV and Grid charging	 PV+grid → battery+load All electricity generated by the PV is used to charge the battery, and concurrently, power is drawn from the grid to charge the battery based on the Max Utility Charge Current. For specific settings, please refer to "10.4 Export Control".
Discharge Period	Battery discharge	 Battery+grid → load The battery discharges to supply the load until the battery voltage is less than the Battery Stop Discharge Voltage or SOC, after which the load will be supplied by the grid.
Outside of peak- valley scheduled time periods	The battery charges acc battery charging source	cording to the priority settings of the mode.

Table 2-11 Description of Force Time Use mode

* Note:

For Vietnam, there are additional **Charge Stop VOL/SOC** (the battery will cease charging when reach this value) and **Max Charge Power** that can be set for the charge periods and **Max Discharge Power** for the discharge periods.

System Overview




Figure 3	3-1	System	diagram
riguic .	J T	System	ulagraffi

Item	Description
X1-Lite-LV series inverter (the device covered in this manual)	The X1-Lite-LV series inverter is an energy storage inverter that supports grid connection of photovoltaic system.
PV modules	PV modules work in MPPT mode. The maximum number of MPPT is two for 8 kW and 10 kW inverters and three for 12 kW inverters.
Battery	The series inverter should be coupled low voltage battery (Lithium or Lead-Acid). The battery with the same capacity and the same model can be installed simultaneously. It communicates with the inverter via BMS and must comply with the specifications of the regulations.
Meter/CT	The meter/CT is used by the inverter for import / export or consumption readings, and manages the battery charge / discharge accordingly for smart energy management applications.

ltem	Description
Generator	SolaX PV-Genset solution ensures optimum interaction between the photovoltaics and diesel generator, which saves fuel, lowers energy costs and ensures a stable and reliable power supply.
Grid	220 V / 230 V and 240 V grid are supported.
SolaXCloud	SolaXCloud is an intelligent, multifunctional monitoring platform that can be accessed either remotely or through a hard wired connection. With the SolaXCloud, the operators and installers can always view key and up to date.

4 Transportation and Storage

If the inverter is not put into use immediately, the transportation and storage requirements need to be met:

Transportation

- Observe the caution signs on the packaging of inverter before transportation.
- Pay attention to the weight of the inverter. Carry the inverters by the required number of personnel as specified by local regulations.
- Wear protective gloves when carrying the equipment by hand to prevent injuries.
- When lifting up the inverter, hold the bottom position of the carton. Keep the inverter horizontal in case of falling down.




Figure 4-1 Caution signs on the packaging

Storage

- The inverter must be stored indoors.
- Do not remove the original packaging material and check the outer packaging material regularly.
- The storage temperature should be between -40°C and +70°C. The relative humidity should be between 4%RH and 100%RH.
- Stack the inverter in accordance with the caution signs on the inverter carton to prevent their falling down and device damage. Do not place it upside down.


5.1 Selection of Installation Location

The installation location selected for the inverter is quite critical in the aspect of the guarantee of machine safety, service life and performance. It has the IP65 ingress protection, which allows it to be installed outdoor. The installation position shall be convenient for wiring connection, operation and maintenance.

5.1.1 Environment Requirement

Make sure the installation environment meets the following conditions:

- The ambient temperature: -25°C to +60°C.
- The relative humidity shall be between 4-100%RH.
- Do not install the inverter in the areas where the altitude exceeds 3000 m.
- Install the inverter in a well-ventilated environment for heat dissipation. You are
 recommended to install an awning over the inverter if it is installed on a support
 outdoor.
- Do not install the inverter in areas with flammable, explosive and corrosive materials or near antenna.
- Avoid direct sunlight, rain exposure and snow accumulation.



NOTICE!

- For outdoor installation, precautions against direct sunlight, rain exposure and snow accumulation are recommended.
- Exposure to direct sunlight raises the temperature inside the device. This temperature rise poses no safety risks, but may impact the device performance.
 - Install the inverter at least 500 meters away from the coast and avoid sea breeze directly hit.




Figure 5-1 Recommended installation position




Figure 5-2 Incorrect installation position

NOTICE!

• For the installation of the whole system, please refer to the specific environment requirement of each unit.

5.1.2 Installation Carrier Requirement

The installation carrier must be made of a non-flammable material, such as solid brick, concrete, etc. and be capable of supporting the weight of the inverter and suitable of the dimensions of the inverter. If the wall strength is not enough (such as wooden wall, the wall covered by thick layer of decoration), it must be strengthened additionally.




Figure 5-3 Installation carrier requirement

5.1.3 Clearance Requirement

The minimum clearance reserved for the connected terminal at the bottom of inverter should be 14 cm. When planning installation space, it is important to consider the bending radius of the wires.

To guarantee proper heat dissipation and ease of disassembly, the minimum space around the inverter must meet the standards indicated below.

For installations with multiple inverters, make sure to leave a minimum space of 60 cm between each inverter. In areas with high ambient temperatures, increase the clearances between the inverters and provide adequate fresh air ventilation if feasible.




Figure 5-4 Clearance requirement for single inverter




Figure 5-5 Clearance requirement for multiple inverters

5.2 Tools Requirement

Installation tools include but are not limited to the following recommended ones. If necessary, use other auxiliary tools on site. Please note that the tools used must comply with local regulations.



5.3 Additionally Required Materials

Table 5-1 Additionally required wires	
---------------------------------------	--

			• •			
No.	Required Material		Туре	Conductor Cross-section		
1	PV wire	Q	Dedicated PV wire with a voltage rating of 600 V	4-6 mm ²		
2	Communication wire	Mar .	Network cable CAT5E	0.2 mm ²		
3	Battery power cable	×	Conventional copper wire	35-50 mm²		
4	Additional PE wire	Q	Conventional yellow and green wire	10-16 mm²		
Table 5-2 Wire and breaker recommended for Grid connection						
	Model	8 kW	10 kW	12 kW		
Wire (cop		10 mm	² 16 mm ²	16 mm²		
Circu breal		60 A	80 A	100 A		
Table 5-3 Wire and breaker recommended for EPS connection						
Model 8		8 kW	10 kW	12 kW		
Wire V 8 mr (copper) 8 mr		8 mm²	² 10 mm ²	16 mm²		
Circuit breaker		50 A	60 A	80 A		

Model		8 kW	10 kW	12 kW
Wire (copper)	Y	10 mm²	16 mm²	16 mm²
Circuit breaker		60 A	80 A	100 A

Table 5-4 Wire and breaker recommended for GEN connect
--

6 Unpacking and Inspection

6.1 Unpacking

- The inverter undergoes 100% testing and inspection before delivery. However, damages may still occur during transportation. Before unpacking, please carefully check the external packaging for any signs of damage, such as punctures or cracks.
- Unpacking the inverter according to the following figure.

Figure 6-1 Unpacking the inverter

- Properly handle all the packaging materials in case they may be reused for storage and transportation of the inverter in the future.
- Upon opening the package, check whether the inverter is intact and whether all accessories are included. If any damage is found or any parts are missing, contact your dealer immediately.

6.2 Scope of Delivery




Table 6-1 Packing list

ltem	Description	Quantity	Remark
/	Inverter	1 pc	
/	Bracket	1 pc	
A	Negative PV connector	4 pairs for 8kW~10kW inverters 6 pairs for 12kW inverter	
В	Negative PV pin contact	4 pairs for 8kW~10kW inverters 6 pairs for 12kW inverter	
С	Positive PV connector	4 pairs for 8kW~10kW inverters 6 pairs for 12kW inverter	
D	Positive PV pin contact	4 pairs for 8kW~10kW inverters 6 pairs for 12kW inverter	
E	СТ	1 pc	
F	Battery temperature sensor	1 pc	For measuring the temperature of battery

Item	Description	Quantity	Remark
G	Disassembling tool for PV terminal	1 pc	
Н	Battery connection terminal	4 pcs	
I	Y terminal	9 pcs	For Grid, EPS, GEN connection
J	OT terminal	1 pc	For grounding
k	M4*L12 screw	2 pcs	For fixing the inverter
L	M6*L14 screw	1 pc	For grounding
М	Washer	4 pcs	For fixing the bracket
Ν	Expansion tube	4 pcs	For fixing the bracket
0	Self-tapping screw	4 pcs	For fixing the bracket
Р	RJ45 terminal	4 pcs	
Q	RJ45 connector	2 pcs	
R	Document	/	
S	Decorative buckle	2 pcs	For decorating the lower cover
Т	Parallel network cable	1 pc	For parallel connection
/	Dongle (Optional)	1 pc	

NOTICE!

• Refer to the actual delivery for the optional accessories.

7 Mechanical Installation

\Lambda warning!

- Only qualified personnel are allowed to perform the mechanical installation following local laws and regulations.
- Check the existing power cables or other piping in the wall to prevent electric shock or other damage.
- Use insulated tools and wear personal protective equipment throughout the installation and maintenance process.

• During installation, always be cautious about the weight of the inverter. Improper lifting or dropping of the inverter may result in personal injury.

NOTICE!

• Install the inverter at a maximum back tilt of 15 degrees and avoid forward tilted, side tilted, or upside down.




Figure 7-1 Correct installation




Figure 7-2 Incorrect installation

7.1 Dimensions for mounting

Before installation, check the dimensions of the wall mounting bracket and ensure that enough space is reserved for the installation and heat dissipation of the entire system.




Figure 7-3 Dimensions 1 (Unit: mm)




Figure 7-4 Dimensions 2 (Unit: mm)

7.2 Installation procedures

Step 1: Horizontally align the wall mounting bracket with the wall, adjust the position of the bracket with a spirit level until the bubble stays in the middle, and then mark holes. The minimum distance between the ground and the inverter is 1200 mm.




Figure 7-5 Marking the holes

Step 2: Set the wall mounting bracket aside and drill holes with Ø10 drill bit. The depth of the holes should be over 80 mm.




Figure 7-6 Drilling holes

Step 3: Knock the expansion tubes (Part N) into the holes. Attach the wall mounting bracket on the wall again. Insert the self-tapping screws (Part O) into the holes and secure it to the wall by torque wrench.




Figure 7-7 Knocking the expansion tubes




Figure 7-8 Securing the wall mounting bracket

Step 4: If the inverter needs to be temporarily placed on the ground, use foam or other protective materials to protect it against potential damages. Lift up the inverter collaboratively by the required number of personnel in accordance with the local regulation and hang it onto the wall mounting bracket. Make sure that the hanging holes of the inverter are properly inserted into the lugs of the bracket.




Figure 7-9 Hanging the inverter





Figure 7-10 Hanging the inverter



Step 5: Use M4*12 screws (Part K) to secure the inverter on both sides.

Figure 7-11 Securing the inverter

8 Electrical Connection

DANGER!

• Before electrical connection, make sure the DC switch and AC breaker are disconnected. Otherwise, the high voltage may cause electric shock, resulting in severe personal injuries or even death.

\Lambda WARNING!

- Only qualified personnel are allowed to perform the electrical connection following local laws and regulations.
- Strictly follow the instructions of this manual or other related documentation for electrical connection. Inverter damages caused by incorrect wiring is not covered by the warranty.
- Use insulated tools and wear personal protective equipment throughout the electrical connection process.

8.1 Terminals of Inverter




Figure 8-1 Terminals of Inverter

Table 8-1	Description	of terminals
-----------	-------------	--------------

Item	Description	Remarks
A	PV connection terminal	PV1 ~ PV4 terminals for 8 and 10 kW inverter; PV1 ~ PV6 terminals for 12 kW inverter
В	Battery connection terminal	
С	COM communication terminal	Including DI/COM, DO, BMS, DRM, METER/CT_1, METER/CT_2, Parallel_1, Parallel_2
D	Upgrade/Dongle terminal	
E	EPS connection terminal	
F	GEN connection terminal	
G	GRID connection terminal	
Н	Fan	
I	DC switch	

8.2 PE Connection

The inverter must be reliably grounded. The PE connection point has been marked with

 $\left(\frac{1}{2}\right)$ It is recommended to connect the inverter to a nearby grounding point.

PE connection procedures

Step 1: Strip the insulation of the PE cable to an appropriate length.




Figure 8-2 Stripping the PE cable

Step 2: Pull the heat-shrink tubing over the PE cable and insert the stripped section into the OT terminal (Part J).




Figure 8-3 Installing the tubing and OT terminal

Step 3: Crimp it with crimping tool, pull the heat-shrink tubing over the crimped section and use a heat gun to shrink it so that it can be firmly contacted with the terminal.




Figure 8-4 Crimping the cable




Figure 8-5 Shrinking the tubing

Step 4: Connect the assembled PE cable to the grounding point of the inverter, and secure it with the M6*14 screw (Part L) in the packing list. (Torque: 3 ± 0.3 N·m)




Figure 8-6 Securing the PE cable

8.3 EPS, GEN and GRID Connection

NOTICE!

• Before connecting the inverter to the grid, approval must be received by local utility as required by national and state interconnection regulations.

The inverter supports the EPS mode. When connected to the grid, the inverter outputs go through the Grid terminal, and when disconnected from the grid, the inverter outputs go through the EPS terminal.

Requirements for EPS, GEN and GRID connection

- Grid voltage requirement
 - » The grid voltage and frequency must be within the allowable range (220 V / 230 V / 240V, 50 / 60 Hz) and comply with the requirements of the local power grid.
- Residual Current Device (RCD)
 - » The inverter has an integrated Type-B Residual Current Monitoring Unit (RCMU). If an external RCD is required by local regulations, a 300 mA Type-A RCD is recommended. If required by local regulations, a Type-B RCD is also permitted.
- AC breaker
 - » An AC breaker that matches the power of the inverter must be used between the inverter output and the power grid. Each inverter must be equipped with an independent breaker or other load disconnection unit to ensure the safe disconnection from the grid. For specific information on the AC breaker for Grid, EPS and GEN, see "5.3 Additionally Required Materials".
- EPS load
 - » Make sure that the rated power of the EPS load is within the rated output power range of the inverter. Otherwise, the inverter will report an **Overload Fault** alarm. In this case, turn off some loads to suit the rated EPS output power range of the inverter, and then press the **ESC** key on the LCD screen to clear the fault.
 - » When connecting to the EPS terminal, pay attention to the following points:

Medical equipment	Connection prohibited
Precision instrument	Connection prohibited
Appliances susceptible to malfunctions in the event of power outages during use.	Connection prohibited

» For inductive loads such as refrigerators, air conditioner, washing machine, etc., ensure that their start power does not exceed the EPS peak power of the inverter.

Equipment	Start power
Lamp	Rated power
Fan	Rated power
Hair dryer	Rated power
Refrigerator	3-5 times rated power
Air conditioner	3-6 times rated power
Washing machine	3-5 times rated power
Microwave oven	3-5 times rated power
	Lamp Fan Hair dryer Refrigerator Air conditioner Washing machine

Table 8-2 EPS load informatic

* Refer to the nominal start power of the equipment for the actual start power.

Wiring procedures

NOTICE!

- Please refer to the table in Additionally Required Materials to view the recommended wire sizes for GRID, EPS, and GEN.
- For 8 kW inverter, the size of Y terminal is 10 mm². For 10 kW and 12 kW inverters, the size of Y terminal is 16 mm².
- **Step 1:** Prepare three-core cables as the EPS, GEN and GRID cables and strip the insulation of L, N and the grounding conductor to an appropriate length. Insert the conductors L, N, and grounding conductor into the Y terminals (Part I).




Figure 8-7 Stripping cables




Figure 8-8 Stripping cables

Step 2: Use crimping tool to crimp it. Make sure the conductors are correctly assigned and firmly seated in the Y terminals.




Figure 8-9 Crimping the conductors

Step 3: Use a cross screwdriver to loosen the M6 screws on both sides of the inverter. Then remove the lower cover of the inverter.(Torque: 3 ± 0.3 N·m)




Figure 8-10 Loosening the screws




Figure 8-11 Removing the lower cover

Step 4: Disassemble EPS, GEN and GRID ports. And remove the plugs and sealing cover as shown below. It is recommended to seal unused plugs with fireproof putty.




Figure 8-12 Removing the plugs




Figure 8-13 Removing the plugs



Step 5: Find the location of EPS, GEN and GRID connection port.




Figure 8-14 Finding the location

Step 6: Thread EPS, GEN and Grid cables through the corresponding EPS, GEN and Grid ports.




Figure 8-15 Threading the EPS cable




Figure 8-16 Threading the GEN cable




Figure 8-17 Threading the GRID cable

Step 7: Loose the M6 screws to insert the crimped conductors. (Torque: 3 ± 0.3 N·m)




Figure 8-18 Loosening the EPS screws




Figure 8-19 Loosening the GEN screws




Figure 8-20 Loosening the GRID screws

Step 8: Insert the crimped conductors L, N, and grounding conductor into the terminals according to the wire sequence and tighten the screws with a cross screwdriver (Torque: 3 ± 0.3 N·m). Then tighten the swivel nut.




Figure 8-21 Connecting the EPS cable




Figure 8-22 Connecting the GEN cable




Figure 8-23 Connecting the GRID cable



• Before powering on the inverter, seal the unused terminals of EPS, GRID and GEN with the plugs. Otherwise, electrical shock may be caused by high voltage, resulting in serious personal injury or death.

8.4 PV Connection

\Lambda DANGER!

- When exposed to the sunlight, PV modules will generate lethal high voltage. Please take precautions.
- Before connecting the PV modules, make sure that both DC switch and AC breaker are disconnected, and that the PV module output is securely isolated from the ground.

WARNING!


• To mitigate the risk of fire, it is crucial to utilize a dedicated crimping tool specifically designed for PV installations to ensure secure and reliable connections.

• Power is fed from more than one source and more than one live circuit.

Requirements for PV connection

- Open circuit voltage and operating voltage
 - » The open circuit voltage of each module array cannot exceed the maximum PV input voltage (600 V) of the inverter. Otherwise, the inverter may be damaged.
 - » The operating voltage of PV modules must be within the MPPT voltage range (50-550 V) of the inverter. Consider the impact of low temperature on the voltage of the photovoltaic panels, as lower temperatures tend to result in higher voltages.
- PV module
 - » The PV modules within the same MPPT channel are of the same brand. Additionally, the strings within the same channel should have identical quantities, and be aligned and tilted identically.
 - » The positive or negative pole of the PV modules is not grounded.
 - » The positive cables of the PV modules must be connected with positive DC connectors.
 - » The negative cables of the PV modules must be connected with negative DC connectors.

Wiring procedures



Step 1: Strip the insulation of the PV cables to an appropriate length.

Figure 8-24 Stripping the PV cable

Step 2: Insert the stripped cable into the PV pin contact (Part B&D).




Figure 8-25 Inserting the PV pin contact

Step 3: Make sure the PV cable and PV pin contact are of the same polarity. Crimp it with crimping tool for PV terminal. Pay attention to the crimping position.




Figure 8-26 Crimping the terminal

Step 4: Thread the PV cable through swivel nut and insert the cable into the PV connector (Part A&C) .




Figure 8-27 Threading the PV cable

Step 5: A "Click" will be heard if it is connected correctly. Gently pull the cable backward to ensure firm connection. Tighten the swivel nut. Verify that the PV connectors have the correct polarity before connection.




Figure 8-28 Securing the PV cable

Step 6: Use a voltage measuring device which complies with the local regulation to measure the positive and negative voltage of the assembled PV connectors. Make sure the open circuit voltage does not exceed the input limit of 600 V.




Figure 8-29 Measuring the voltage of PV connectors

NOTICE!

- If the voltage reading is negative, it indicates an incorrect DC input polarity. Please check if the wiring connections on the measuring device is correct or PV connectors are not mistakenly connected.
- **Step 7:** Remove the PV terminal caps and connect the assembled PV connectors to corresponding terminals until there is an audible "Click". The PV+ on the string side must be connected to the PV+ on the inverter side, and the PV– on the string side must be connected to the PV– on the inverter side.




Figure 8-30 Removing the PV terminal caps




Figure 8-31 Connecting the PV cable

NOTICE!

• For 8 kW~10 kW inverters, remove PV terminal caps of MPPT1 and MPPT2.



• Seal the unused PV terminals with original terminal caps. If all PV terminals are connected, keep the waterproof caps in a safe place. Reinstall it immediately after removing the connectors from terminals.

8.5 Battery Power Cable Connection

\Lambda DANGER!

- Before connecting the cables, make sure the breaker, power button (if any) and DC switch (if any) of battery is OFF.
- Always ensure correct polarity. Never reverse the polarity of the battery cables as this will result in inverter damage.

NOTICE!

• The power cable of battery is in the battery accessory pack. NOT in the scope of inverter's delivery.

Requirements for battery connection

- Battery
 - » Lithium and Lead-acid battery
 - » The inverter is equipped with two independent battery terminals, allowing for connection to two separate battery strings.
 - » Make sure the input voltage of each BAT terminal is higher than minimum voltage 40 V and lower than maximum input voltage 60 V.
- Micro circuit breaker (MCB)
 - » If the battery is integrated with a readily accessible internal DC breaker, no additional DC breaker is required. If local regulations mandate the use of a DC MCB between the battery and the inverter, install a non-polar DC MCB.
 - » The nominal voltage of DC MCB should be larger than maximum voltage of battery.

Model	X1-Lite-8K-LV	X1-Lite-10K-LV	X1-Lite-12K-LV
Voltage	Nominal voltage of DC breaker should be larger than maximum voltage of battery.		
Current (A)	250	250	300

- Battery configuration information
 - » X1-Lite-LV series inverter matches with SolaX low voltage battery TP-LD53, TP-LD150. A single inverter can match with maximum 16 batteries.

Battery connection diagram




Figure 8-32 Lithium battery connection diagram




Figure 8-33 Lead-acid battery connection diagram

Wiring procedures

Step 1: Strip the insulation of the battery power cable to an appropriate length.




Figure 8-34 Stripping the battery cable

Step 2: Insert the stripped cable into the battery connection terminal (Part H). Use crimping tool for battery to crimp it.




Figure 8-35 Inserting the battery connection terminal

Step 3: Disassemble the BAT+ and BAT- ports. Then remove the plug.




Figure 8-36 Disassembling the terminal





Figure 8-37 Removing the plug



Step 4: Thread the battery cable through swivel nut and the battery terminal.

Figure 8-38 Removing the plug

Step 5: Remove the M8 screws to connect the battery cable. (Torque: $5\pm0.5N\cdot m$)




Figure 8-39 Removing the screws

Step 6: Insert the positive cable into BAT+ port and the negative cable to BAT-port. Use cross screwdriver to tighten the screws (Torque: 5 ± 0.5 N·m). Then tighten the swivel nut. Verify that the battery connectors have the correct polarity before connection.




Figure 8-40 Connecting the battery connector

Battery temperature sensor wiring procedures

- Step 1: Find the battery temperature sensor (Part F) in the accessory bag.
- **Step 2:** Disassemble the COM1/2/3 terminal. You can select any port from COM1/2/3. Pass the battery temperature sensor through the COM port and insert the RJ45 terminal of the battery temperature sensor into the BMS port located inside the inverter. Then attach the terminal of the other end to the lead-acid battery in order to measure the battery temperature.




Figure 8-41 Disassemble the swivel nut and attaching the terminal





Figure 8-42 Inserting the cable into BMS port

8.6 COM Communication Connection

8.6.1 Pin Assignment of COM Terminal

The COM terminal is used for generator state detection, rapid shutdown and remote monitoring via DI/COM terminal, generator start-up via DO terminal, battery communication via BMS terminal, controlling the device response via DRM terminal, Meter and CT connection via METER/CT_1 and METER/CT_2 terminal, parallel connection via PAR_1 and PAR_2 terminal.






Figure 8-43 Pin assignment of COM terminal

8.6.2 DI/COM Connection

DI/COM terminal is designed to support generator state detection, rapid shutdown and remote monitoring through dry contact input.

To enhance safety and reduce the risk of injury, you can install the emergency stop switch in a readily accessible location through dry contact connection. In the event of an emergency, this switch can be easily reached and pressed to promptly switch off the entire system, ensuring a swift response and preventing further harm.

DI/COM pin assignment

	Pin	Pin assignment
5	1	DI_1
rapid shutdown (dry contact input)	2	DI_2
	3	/
For remote monitoring	4	RS485A
(dry contact input)	5	RS485B
	6	GND
	7	/
	8	/

Table 8-3 DI/COM pin assignment

8.6.3 DO Connection

DO terminal is designed to support generator start-up through dry contact output.

DO pin assignment

	Table 6-4 DO pill assignment	
	Pin	Pin assignment
	1	DO2_1
	2	/
	3	DO2_2
	4	/
	5	/
For generator start-up (dry contact output)	6	DO1_1
	7	/
For generator start-up (dry contact output)	8	DO1_2

Table 8-4 DO pin assignment


8.6.4 BMS Communication Connection

Through BMS communication terminal, the inverter can communicate with the battery.

8.6.5 DRM Connection (Applicable to AS/NZS 4777.2)

According to AS/NZS 4777.2, the inverter needs to support the function of demand response mode (DRM). With the use of an external control box, active or reactive power regulation can be realized in a timely and fast manner, and the inverter can be operated stably during the process of regulation.

DRM 0, DRM 1 and DRM 5 are available now.






Table 8-5 Desciptions of DRM

Mode	Pin	Requirement
DRM 0	Pin 6	When S0 is turned on, the inverters shut down.When S0 is turned off, the inverters restore grid connection.
DRM 1	Pin 1	• When S1 is turned on, the inverters do not input active power.
DRM 5	Pin 1	• When S5 is turned on, the inverters do not output active power.

8.6.6 Meter/CT Connection

The inverter should work with an electric meter or current transformer (CT for short) to monitor household electricity usage. The electricity meter or CT can transmit the relevant electricity data to the inverter or platform.

• Smart meters must be authorized by our company. Unauthorized meter may be incompatible with the inverter, thereby resulting in inverter damage and working mode malfunction. SolaX will not be responsible for the impact caused by the use of other appliances.

NOTICE!

- Do not place the CT on the N wire or ground wire.
- Do not put CT on the N wire and L wire at the same time.
- Do not place the CT on the side where the arrow points to the inverter.
- Do not place the CT on non-insulated wires.
- The cable length between CT and inverter should not exceed 100 meters.
- It is recommended to wrap the CT clip around in circles with insulating tape.

Meter/CT connection diagram

NOTICE!

- The following diagrams take SolaX authorized DTSU666 meter connection for example.
- If you have other power generation equipment (such as an inverter) at home and wants to monitor both equipment, our inverter provides Meter 2 communication function to monitor the power generation equipment. For more information, please contact us.
- Please make PE connection for Meter if the meter has ground terminal.
 - Meter connection diagram




Figure 8-45 Meter connection diagram

• CT connection diagram




Figure 8-46 CT connection diagram

Meter/CT_1 pin assignment

	Pin	Pin assignment
	1	/
	2	/
For CT connection	3	CT1_1
E M.1	4	METER_485A
For Meter connection	5	METER_485B
For CT connection	6	CT1_2
	7	/
	8	/

Meter/CT_2 pin assignment

	Pin	Pin assignment
	1	/
	2	/
For CT connection	3	CT2_1
	4	METER_485A
For Meter connection	5	METER_485B
For CT connection	6	CT2_2
	7	/
	8	/

8.6.7 Parallel Connection

The inverter provides the parallel connection function. One inverter will be set as the **Master** inverter to control other **Slave** inverters in the system. For details, please refer to "15.1 Application of Parallel Function".

8.6.8 Wiring procedure of COM Communication Connection

Meter/CT wiring procedure

Step 1: Disassemble the COM port, then remove the plug. For communication connection, you can select any port from COM1/2/3. For unused terminals, keep the plug to protect the terminal.




Figure 8-47 Removing the plug

Step 2: Crimp RJ45 terminal (Part P). It is recommended to use CAT5 network cable.

For CT connection without RJ45 connector (Part Q), there is no need to crimp RJ45 terminal.

For Meter connection, crimp only one RJ45 terminal. (Step a, b)

For CT connection with RJ45 connector, crimp two RJ45 terminals. (Step a, b,c)




Figure 8-48 Crimping RJ45 terminal

Step 3: For Meter connection. Insert one side of the cable (with RJ45 terminal) into the Meter/CT port of the inverter, and the other side into the Meter. Then tighten the swivel nut.




Figure 8-49 Inserting the cable into the Meter/CT port




Figure 8-50 Inserting the cable into the Meter

Step 4: For CT connection without RJ45 connector. Insert the cable with RJ45 terminal side into the Meter/CT port of the inverter. Then tighten the swivel nut.




Figure 8-51 Inserting the cable into the Meter/CT port




Figure 8-52 Tightening the swivel nut

Step 5: For CT connection with RJ45 connector. Insert one side of the cable into the Meter/CT port of the inverter, and the other side into the RJ45 connector. Then insert the RJ45 terminal of the CT into the RJ45 connector. Then tighten the swivel nut.




Figure 8-53 Inserting the cable into the Meter/CT port




Figure 8-54 Inserting the RJ45 terminals into the RJ45 connector

DI/COM, BMS, DO, DRM wiring procedure

Step 1: Thread the cable into the swivel nut, clamping jaw and cable support sleeve. Strip the insulation layer (length: 15mm) at one end of the cable. Crimp RJ45 terminal at the same end of the cable. Pay attention to the pin order of RJ45 terminal. Use a network cable tester to check if the cable has been correctly and properly crimped before connecting to inverter.




Figure 8-55 Cable making procedure




Figure 8-56 Pin order of RJ45 terminal

Step 2: For communication connection, you can select any port from COM1/2/3. Find the location of DI/COM, BMS, DO, DRM port inside the inverter.




Figure 8-57 Finding the COM terminal




Figure 8-58 Finding the DI/COM, BMS, DO, DRM port

Step 3: Insert the assembled cable into the corresponding ports, then tighten the swivel nut.





Figure 8-59 Connecting the DI/COM, BMS, DO, DRM port

Parallel wiring procedure





NOTICE!

• Parallel network cable is in the accessory bag.

Close the lower cover

Step 1: Put the lower cover back to the inverter. Use cross screwdriver to tighten the screws on both sides. (Torque: 3 ± 0.3 N·m)




Figure 8-61 Put the lower cover back




Figure 8-62 Tighten the screws

Step 2: Install the two decorative buckles (Part S) to the two screws form the accessory bag.




Figure 8-63 Installing the decorative buckles

8.7 Monitoring Connection

The inverter provides a Dongle terminal, which can transmit data of the inverter to the monitoring website via WiFi+LAN dongle (Optional). The WiFi+LAN dongle is equipped with two kinds of communication modes (Wi-Fi mode or LAN mode). Users can choose based on actual needs.

Monitoring connection diagram




Figure 8-64 Wi-Fi mode connection diagram




Figure 8-65 LAN mode connection diagram

Monitoring wiring procedure

Wi-Fi mode:

a. Assemble the dongle.




Figure 8-66 Assembling the dongle

b. Plug the dongle to the inverter.




Figure 8-67 Dongle connection procedure

🕂 CAUTION!

• The buckles on the inverter and dongle must be on the same side. Otherwise, the dongle may be damaged.

NOTICE!

- The distance between the router and the inverter must be no more than 100 meters. If there are walls in between, the distance must be no more than 20 meters.
- For locations where Wi-Fi signals are weak, install a Wi-Fi signal booster.

NOTICE!

• For details on Wi-Fi configuration, see *Pocket WiFi + LAN Installation Manual.* You can configure Wi-Fi only after the inverter is powered on.

LAN mode:

a. Disassemble the waterproof connector into components 1, 2, 3 and 4; Component 1 is not used. Keep it in a safe place.




Figure 8-68 Disassembling the waterproof connector

b. Assemble the dongle.




Figure 8-69 Assembling the dongle

c. Plug the dongle to the inverter.


9 System Commissioning


No.	ltem	Checking details		
1	Installation	The inverter is installed correctly and securely. The battery is installed correctly and securely. Other device (if any) is installed correctly and securely.		
2	Wiring	All DC, AC cables and communication cables are connected correctly and securely; The meter/CT is connected correctly and securely. The ground cable is connected correctly and securely;		
3	Breaker	All the DC breakers and AC breakers are OFF;		
4	Connector	The AC and DC connectors are connected; The connectors on the Grid and EPS terminal are connected correctly and securely.		
5	Unused terminal	Unused terminals and ports are locked by waterproof caps.		
6	Screw	All the screws are tightened.		

9.1 Checking before Power-on


9.2 Powering on the System

- **Step 1:** Turn on the AC breaker between the inverter and the public grid.
- **Step 2:** Turn on the AC breaker between the inverter and the EPS loads.
- Step 3: Turn on the DC switch between the PV string and the inverter. (if any)
- **Step 4:** Turn on the DC switch between the battery and the inverter.






Step 6: If the battery is connected, but PV and Grid are not connected. Press and hold the battery button until the screen is on. If PV or Grid is connected, skip this step.



Step 7: Turn on the system button at the left side of the inverter, the light on the system button will light up. Then the inverter will start automatically.



10 Operation on LCD

10.1 Introduction of Control Panel




Figure 10-1 Control Panel

- While upgrading, the green, blue and red indicator lights will flash in turns and the breathing light also flashes the three colour in turns, indicating that the upgrade is in progress.
- In error state, an error alarm will be displayed at the LCD screen, please check the information and refer to corresponding solutions in the troubleshooting.

ltem	Definition
LCD screen	Display the information of the inverter. You can tap on the icons to check and reset the parameters.

LED indicator	Status		Definition
		Solid green	The inverter is in grid-connected operation state or off-grid operation state.
Operating		Green blinking	The inverter is in the process of powering on.
		Light off	The inverter is in a fault or manual shutdown state.
Ē		Solid blue	One battery is connected in a normal state at least.
Battery		Light off	Low battery voltage or no battery.
\wedge		Solid red	The inverter is in a fault state.
Error		Light off	The inverter has no faults or alarms.
Breathing light	Status		Definition
		Green blinking	Both inverter and battery are in normal status.
°°°°°°		Red blinking	The inverter or battery has alarm information or fault.
		Blue blinking	The battery is in normal status, but the battery SOC is lower than the setted Min SOC.
Breathing light		Green, blue and red lights flash in turns	The upgrade is in progress. After successfully upgraded, the light turns green and the buzzer sounds for one second.

Table 10-1 Definition of indicators

Table 10-2 Definition of keys

Кеу	Definition
ESC key	Return to the superior menu or cancel setting value.
Up key	Turn to the previous page.
Down key	Turn to the next page.
Enter key	Confirm the selection.

10.2 Introduction of Menu Interface

The default menu is shown as below. In this interface, you can tap on the four icons of PV, battery, grid and load to check the basic information of each part.



• Inverter: You can **Power ON/OFF** the inverter after tapping the icon of the inverter. Information contains the inverter voltage, inverter current, inverter power, input/export electric energy of the inverter today and total input/export electric energy since the inverter activated for the first time (Positive value means power output; Negative value means power input).

Return		
Inverter		ON 🌔
	Inv Vol:	0.2 V
	Inv Curr:	1.00 A
•	Inv Power:	0.00 kW
-	Today:	0.0kWh
111	Total:	0.0kWh

• PV: Display the PV information of the system, containing input voltage, current and power situation of each MPPT.

G Return				
PV				
6.00 KW Power	PV 1: PV 2: PV 3:	0.0V	0.0 A	2.0 KW

 Battery: Display the information of battery. Information contains the power, voltage, current, temperature and SOC status. Tap the BMS detail (Only available for SolaX Lithium battery), you can see the battery's SN number and Version.

🛛 Return	
Battery	BMS Detail >
	Power: 1000 W
80%	Voltage: 8.6 V
00%	Current: 0.0A
VOL: 0.0V	Temp: -40 °C

• Grid: Information contains the voltage, current, output power, and frequency of Grid terminal. And information of feed-in and consumption power today and total.

Return							
Grid							
Voltage:	0.2V	Current:	1.0A				
Power:	0W	Freq:	0.00Hz				
Feed_in:	Today=2.2kWh	Total=2	2.2kWh				
Consum:	Today=2.2kWh	Total=2	2.2kWh				


 Load: Information contains the total load, the voltage, current and frequency of load.

C Return		
Load		
10.00 KW Total Load	Vol: Curr: Freq:	0.2 V 1.00 A 50.00 Hz

 Settings: After tapping the setting icon on the upper right corner, you can enter the submenus interface. There are eight submenus in the menu that can be selected for relevant setting operations.



Work Mode: Select the working mode of the inverter, including Work mode for Pakistan : SUB, SBU, MKS/EPS and Force Time Use and Work mode for other countries: Back Up, Self Consumption and Force Time Use.




» Export Control: Set whether or not feeding power to the grid (Including No Export and Export) and Max Utility Charge Current.

	\square	No Export
Export Control	-(Export
	Ц	Max Utility Charge Current


» Battery Settings: Select Battery Type and set Charge Source.



- » About: Here you can see some basic information of the inverter.
- » Smart Load: Set the generator port connections including: None, Load and Generator.



» Setting: Set the parameters of the inverter, including Basic and Advance.



- » History Errors: Display the history data of errors.
- » Parallel Setting: Set the parameters of parallel.

10.3 Work Mode

Please refer to "2.7 Working Mode" for introduction and working logic of the work modes.


Setting path: @>Work Mode

After entering into the default menu, select the **Setting icon**, then you can set work mode for Pakistan and work mode for other countries as follows:

Work Mode for Pakistan

To select the Pakistan work modes, please tap "Country" on the **Basic** interface (**Inverter**> **Setting** > **Basic**) and select "Pakistan" first. You can refer to "Country" section for details. There are four work modes for Pakistan: **SUB**, **SBU**, **MKS/EPS** and **Force Time Use**.

• SUB



- SBU
 - » Return to Utility Voltage/SOC: When the voltage/SOC is lower than the setted value, the battery starts to charge. (For lead acid battery) Default: 46 V, range: 42~47 V; (For Lithium battery) Default: 20%, range: 10~75%.
 - » Return to Battery Voltage/SOC: When the voltage/SOC is higher than the setted value, the battery starts to discharge.
 (For lead acid battery) Default: 54 V, range: 48~59 V;
 (For Lithium battery) Default: 80%, range:25~90%.

The minimum difference between the above two parameters is 2 V for lead acid battery and 5% for Lithium battery.

» Charge to Full (only for lead acid battery): Disabled by default. When enabled, the battery will be charged to full capacity first without discharging.

• Return			
SUB	SBU	MKS/EPS	Force Time Use
SBU			
Return t	o Utility Vo	46V	
Return t	o Battery V	54V	
Charge	to Full		

MKS/EPS

» Return to SUB Mode:

(For lead acid battery) Default: 42.0 V, range: 40.0~56.0 V; (For Lithium battery) Default: 20%, range: 10~80%.

» Return to SBU Mode:

(For lead acid battery) Default: 58.0 V, range: 44.0~58.0 V (For Lithium battery) Default: 100%, range: 25~100%.

O Return							
SUB	SBU	MKS/EPS	Force T	ïme Use			
MKS/EPS	MKS/EPS (IF SOLAR POWER PRESENT)						
Return to	Return to SUB Mode						
Return to	Return to SBU Mode						

Force Time Use

- » **Charge Period**: You can set three charge periods (start time and end time) here and set the charge source (**PV Only**, **PV Then Grid**, **PV and Grid**).
- » Home Load Removed From Utility Time Periods: You can set three discharging periods here.
- » Battery Stop Discharge VOL/SOC: When the battery voltage/SOC is lower than the set value, the battery will stop discharging.
 (For lead acid battery) Default: 43.0 V, range: 42.0~47.0 V
 (For Lithium battery) Default: 10%, range: 5~40%.

J MKS/	EPS Fo	orce Tim	e Use	SUB	SBU	MKS/EPS	S Force	e Time
				Home Lo	ad Remove	d From Ut	ility Time Pe	riods
End	Source			Start	00 : 00	End	00:00	
00:00	PV Only	•			00 : 00		00 : 00	
00 : 00	PV Only	•			00:00		00 : 00	
00 : 00	PV Only	•	Ť	Battery	Stop Discha	arge VOL	43.0 V	
	00:00	00 : 00 PV Only 00 : 00 PV Only	00 : 00 PV Only ▼ 00 : 00 PV Only ▼	End Source 00 : 00 PV Only V 00 : 00 PV Only V	End Source Start 00 : 00 PV Only 00 : 00 PV Only	End Source Start 00 : 00 00 : 00 PV Only ▼ 00 : 00 00 : 00 PV Only ▼ 00 : 00	End Source Start 00 : 00 End 00 : 00 PV Only ▼ 00 : 00 00 00 00 : 00 PV Only ▼ 00 : 00 00	End Source Start 00 : 00 End 00 : 00 00 : 00 PV Only ▼ 00 : 00 00 : 00 00 : 00 00 : 00 PV Only ▼ 00 : 00 00 : 00 00 : 00 00 : 00 PV Only ▼ 00 : 00 00 : 00 00 : 00

Work Mode for other countries

There are three work modes for other countries: **Back Up**, **Self Consumption** and **Force Time Use**.

Back Up

G Return		
Back Up	Self Comp	Force Time Use
Back Up		✓

- Self Consumption
 - » Battery or Load First: There are three options: Self Comp, Battery First and Load First.
 - » Return to Utility Voltage/SOC: When the voltage/SOC is lower than the setted value, the battery starts to charge. (For lead acid battery) Default: 46 V, range: 42~47 V; (For Lithium battery) Default: 20%, range: 10~70%.
 - » Return to Battery Voltage/SOC: When the voltage/SOC is higher than the setted value, the battery starts to discharge.
 (For lead acid battery) Default: 54 V, range: 48~59 V;
 (For Lithium battery) Default: 80%, range:20~90%.

The minimum difference between the above two parameters is 2 V for lead acid battery and 5% for Lithium battery when **Self Comp** is selected.



Force Time Use

For most countries, the setting interfaces are as below:

- » Charge Period: You can set three charge periods (start time and end time) here and set the charge source (PV Only, PV Then Grid, PV and Grid).
- » Discharge Period: You can set three discharging periods here.
- Battery Stop Discharge: When the battery voltage/SOC is lower than the set value, the battery will stop discharging.
 (For lead acid battery) Default: 43.0 V, range: 42.0~47.0 V
 (For Lithium battery) Default: 10%, range: 5~40%.

leturn				G Return			
ack Up	Self Comp	p For	rce <u>Tim</u> e Use	Back Up	Self	Comp	Force
harge Period			~	Dischar	ge Period		
Start	End	Source		Start	00 : 00	End	00:00
00 : 00	00 : 00	PV Only			00:00		00 : 00
00 : 00	00 : 00	PV Only	 		00 : 00		00 : 00
00:00	00:00	PV Only	▼ Ť	Battery	Stop Dischare	ae	43.0 V

For Vietnam, the setting interfaces are slightly different with more parameters to be set. You can select to set each **Charge Period** and **Discharge Period**. Except start time, end time and charging source for charge period, and start time, end time for discharge period, the following can be set:

- » Charge Stop VOL/SOC: When the battery voltage/SOC is higher than the set value, the battery will stop charging.
 (For lead acid battery) Default: 58.0 V, range: 47.0~60.0 V
 (For Lithium battery) Default: 99%, range: 20~99%.
- » Max Charge Power: Maximum allowable charging power. Default: 6000 W, range: 1~12000 W.
- » Discharge Stop VOL/SOC: When the battery voltage/SOC is lower than the set value, the battery will stop discharging.
 (For lead acid battery) Default: 42.0 V, range: 40.0~52.0 V
 (For Lithium battery) Default: 10%, range: 10~40%.
- » Max Charge Power: Maximum allowable discharge power. Default: 6000 W, range: 1~12000 W.

Back Up	Self Comp							
		Force	Time Use	Back Up	р	Self Comp	Force	Time U
P1 🔻	Charge Period			P1	▼ 1	Discharge Peric	od	
Start 00 : 00	End	00:00		Start	00 : 00	End	00 : 00	
Charge Stop VC	DL	58.0 V		Dischar	ge Stop V	OL	42.0 V	
Max Charge Po	wer	6000 W		Max Dis	charge P	ower	6000 W	
Source	PV C	Dnly 🔻	~					

10.4 Export Control

Setting path: <a>Setting Path:

Here users can choose between feeding excess PV power into the grid or limiting it.

- **No Export:** Disallow feeding power into the grid.
 - » Device Bias Power: The inverter will be biased to take power from the grid. Default: 0 W; Range: 0 W ~ 2% rated output power.
- **Export:** Allow feeding power into the grid and enables to set the percentage of power to be fed in as needed. Range: 0~100%
- **Max Utility Charge Current**: Setting the current that can be taken from the power grid when the battery is charged. Default: 20 A; Range: 0~250 A.

Return		G	Return	
Setting			Setting	
Vo Export			No Export	
Export	0 %		Export	100 %
Max Utility Charge Current(A)	20 A		Max Utility Charge Current(A)	20 A
Device Bias Power	0 W			

10.5 Battery Setting

Setting path: <a>>Battery Setting

• **Battery Type:** Select the battery type according to the actual battery used.

Country	Battery type	Option
	Lead Acid	AGM, FLD, TBL
Pakistan	Lithium	SolaX-LV, Pylon, Volta, Lemoen, Lanni, Soluna
	User	User (User defined)
	Lead Acid	Lead Acid
Other countries	Lithium	SolaX-LV, Pylon, Volta, Lemoen, Lanni, Soluna
	User	User (User defined)

Touch the corresponding Battery type to enter the next level. Select from the options (if any) on the upper right and then touch the square on the right side of the displayed option to confirm the selection.

G Return	Return	
1) Battery Type	Lead Acid	2) AGM 🔻
Lead Acid Li-ion	AGM	3) 🔽
User	Max Charge Current	250A
	Max Discharge Current	250A
Charge Source	Min Discharge Voltage	42.0V
V Only PV Then Utility PV and Utility		

After that, you can set the relative parameters.

» Lead acid battery:

Max Charge Current: Default: 250 A, range: 2~250 A Max Discharge Current: Default: 250 A, range: 2~250 A

Min Discharge Voltage: Default: 42.0 V, range: 40.0~47.0 V

G Return	
Lead Acid	AGM 🔻
AGM	
Max Charge Current	250A
Max Discharge Current	250A
Min Discharge Voltage	42.0V

» Lithium battery:

Max Charge Current: Default: 250 A, range: 2~250 A

Max Discharge Current: Default: 250 A, range: 2~250 A

Bat Online Cnt: Display the number of batteries connected.

Battery Parallel Mode (Only for SolaX-LV): Set up the battery parallel mode. **Alone**: Each battery is connected to the inverter separately. **Converge**: All the batteries is converged to the BMS.


@ Return		@ Return	
Li-ion	SolaX-LV	Li-ion	Pylon 🔻
SolaX-LV		Pylon	
Max Charge Current	250A	Max Charge Current	250A
Max Discharge Current	250A	Max Discharge Current	250A
Bat Online Cnt	1	Bat Online Cnt	1
Battery Parallel Mode:	Alone		

» User: Here you can set the parameters of the battery according to your actual needs.

Max Charge Voltage: Default: 58.8 V, range: 49.0~60.0 V Min Discharge Voltage: Default: 42.0 V, range: 40.0~47.0 V Float Charge Voltage: Default: 54.4 V, range: 49.0~59.0 V Max Charge Current: Default: 250 A, range: 2~250 A Max Discharge Current: Default: 250 A, range: 2~250 A

Return	
User	
Max Charge Voltage	58.8V
Min Discharge Voltage	42.0V
Float Charge Voltage	54.4V
Max Charge Current	250A
Max Discharge Current	250A

- **Charge Source:** For charging the battery, there are three options to choose from: PV Only, PV Then Utility and PV and Utility.
 - » PV Only: allows only PV charging.
 - » **PV Then Utility**: prioritizes PV charging and supplements with grid charging when needed.
 - » PV and Utility: allows for both PV and grid charging.



10.6 About

Setting path: @>About

Here you can check the basic information of the inverter.

Return				
About				
Machine S Wi-Fi SN:		670004000 670004000		
	MDSP	HMI	ARM	CPLD
Version	007.05	001.00	003.01	V1.0.0
BootVer	001.00	007.50	001.01	V1.0.0

10.7 Smart Load

Setting path: @>Smart Load

The generator port has three options:

None: No device is connected to the generator port;

Return		
Smart Load	Load	Generator

Load: The generator port is connected to a load;

There are two types of Battery: Lead acid (Voltage type) and Lithium (SOC type).

- » Smart Load Battery off Voltage/SOC: When the voltage/SOC is lower than the setted value, the battery will no longer supply power to the smart load;
- » **Smart Load Battery on Voltage/SOC**: When the voltage/SOC is higher than the setted value, the battery will supply power to the smart load again.

Smart Load Battery off Voltage: Default: 48.0 V, range: 40.0-52.0 V

Smart Load Battery on Voltage: Default: 52.0 V, range: 41.0-53.0 V

Smart Load Battery off SOC: Default: 30%, range: 15-30%

Smart Load Battery on SOC: Default: 50%, range: 30-60%



 Generator: The generator port is connected to the generator. For the details, please refer to "15.2 Application of Generator".

G Return			
Smart Load None	Load	🗹 Gen	erator
Gen Rated Power		8.00kW	1/5
Gen Max Run Time		1000min	
Gen Cool Time		60min	~

10.8 Setting

Settings includes Basic setting and Advance setting.

10.8.1 Basic Setting

Setting path: <a>Setting>Basic

Return	
Setting	
Basic	θ
Advance	0

You can set Country, Grid Code, Language, Mute, Battery Sleep, Lcd Sleep, Date Time, DI Option, DO1 Option and DO2 option in Basic interface.

Setting Safety Code

NOTICE!

- The inverter cannot be connected to the grid before the safety code is correctly set. If there is any doubt about your safety code where the inverter installed, please consult your dealer or SolaX service for details.
- The setup will vary from different safety codes.

You can set safety code according to different countries and grid-tied standards.

Setting Country

This inverter provides multiple countries for customers to choose from according to the installation site.

• Setting Grid Code

After the Country is set, select the applicable Grid Code.

There are several standards to choose from, please refer to the LCD screen on the inverter. (May be changed or added without notice.)

In addition, the inverter has a user defined option which allows you to customize relevant parameters with a wider range. You can select: **Basic>Country>OTHER** and **Basic>Grid Code>USER_DEFINED**. Then complete the parameter settings under **Advance** interface as needed.

Setting Language

You can set the display language.

G Return	
Basic Setting	
Country	PAKISTAN 🔻
Grid Code	PAKISTAN
Language	English

Setting Off-Grid Mute

When the inverter is running in off-grid (EPS) Mode, you can choose whether the buzzer is turned on or not.

- Turn ON, the buzzer mutes.
- Turn off, the buzzer will sound every 4 seconds when the battery SOC is > EPS min. SOC. When the battery SOC is equal to EPS min. SOC, the buzzer will sound with higher frequency at every 400 ms.

Setting LCD Sleep

You can set whether to enable the LCD Sleep function or not.

LCD Sleep state means if you do not operate the screen for a period of time , the screen will stay off.

Setting Battery Sleep

You can set whether to enable the battery sleep function or not.

Battery Sleep state means the battery is in standby state. At this time, it will neither charge nor discharge.

Setting Date Time

You can set the current date and time of the installation site.



Setting DI Option

You can set whether to enable the DI Option or not. **None** means disable the function. **Emerg Stop** means enable the function for emergency stop.

Setting DO1 Option

You can set whether to enable the DO1 Option or not. **None** means disable the function. **Generator** means enable the function to allow communication with the generator.

Setting DO2 Option

You can set whether to enable the DO2 Option or not. None means disable the function.

None	▼
None	▼
None	▼
	None

10.8.2 Advanced Setting

Setting path: ⁽²⁾ >Setting>Advance

Return	
etting	
Basic	0
Advance	0

After tapping the **Advance** interface, you need to enter the password, the default password is "2014".

O Retur	Please Er	nter Pass	word	×	
Settin	Please e	nter four	Arabic n	umerals	
Bas	1	2	3	•63	0
	4	5	6	•	
Adv	7	8	9		0
	٥		•	~	

After entering into the Advance interface, you can set Grid Protection, Active Power Control, Reactive Power Control, PV Connection, Meter/CT State, Com-Parameters, Check Parameters, Reset, New Password and EPS Control here.

Return			Return		E
Advanced Setti	ng		Advanced Sett	ng	
Grid Protection	Active Power Control	Reactive Power Control	Check parameters	Reset	New password
PV Connection	Meter/CT State	Com- parameters	EPS Control		

Setting Grid Protection

When the safety code is selected, the parameters of **Grid Protection** corresponding to the selected safety code will be automatically matched. The default value is the specified value under the current safety regulations. The contents will be displayed according to the requirements of local laws and regulations.

You can also set the parameters according to your actual needs within the range of the specific safety code.

Grid Protecti	on			
Vol Protect	Max1:	225.0 V	Min1:	225.0 V
	Max2:	225.0 V	Min2:	225.0 V
	Max3:	225.0 V	Min3:	225.0 V
Reconnect V	/ol Max:	225.0 V	Vol Min:	225.0 V

Setting Active Power Control

Here you can set the **Power Limit** and **Power Slope** of the active power.

- » Power Limit: Default: 100%, Range:0~110%.
- » Power Slope: Default: 10.0%, Range:1.0~100.0%

Active Power Control	
Power Limit	100%
Power Slope	10.0%

Setting Reactive Power Control

There are four modes can be selected: **PF Mode**, **Fix Q Power**, **PF_P Mode** and **Q(U) Mode**. The default value is the specified value under the current safety regulations. The contents will be displayed according to the requirements of local laws and regulations. Please refer to local grid requirements.

Return				G Re	eturn			
🕑 Reactive P	ower Contro	PF mode	• •	۵	Reactive	Power Contro	Fix Q	ower
Over Excite	ed	🗆 Und	er Excited	Fix	Q Power			1
PF Value			0.100					
Return				3 Re	eturn			
		PF-P Mo	da 🗕	•	Reactive P	Power Control	Q(U)	Mode
Reactive Po	ower Control	PF-P MC	Jue					
Reactive Population PF-Watt En:		PF-P Mt	0.00	Va	r- Volt En:	🕑 Enable		
	🕑 Enable				r- Volt En: r-volt1:	C Enable	Var-volt2:	0.
PF-Watt En: PF-Watt1(P):	Enable 0.00%	PF-Watt2(PF):	0.00	Va			Var-volt2: Var-volt4:	0.0
PF-Watt En:	 Enable 0.00% 0.00% 	PF-Watt2(PF): PF-Watt3(PF):	0.00	Va	r-volt1:	0.00V		_

Setting PV Connection

Here you can set PV connection mode.



Setting Meter/CT State

NOTICE!

• If the user has other power generation equipment (such as inverter) at home and wants to monitor both, the inverter provides Meter/CT_2 communication function to monitor the power generation equipment.

Here you can set Meter/CT1 State and Meter/CT2 State based on the actual application.

CT1 is enabled by default in **Meter/CT1 State**. **None** is set by default in **Meter/CT2 State**. If need to change, select from the upper right and for CT and Meter you need to touch the small square to confirm the selection.

G Return	•	@ Return	
Meter/CT1 State	CT1 🔻	Meter/CT2 State	None 🔻
CT1 Enable	SelfCheck Enable		
CT1 Direction	Positive 🔻		
CT1 Sensitivity	Level1 🔻		

Below screen displays will take **Meter/CT1 State** as examples to describe the parameters. The parameters are basically the same.

- CT: The Meter/CT port is connected to CT;
 - » CT1/2 Direction: Here you can set the direction of CT1/2 to Positive or Negative connection according to the actual situation.
 - » CT1/2 Sensitivity: Here you can set the sensitivity level of CT1/2. There are three levels to choose from: Level1 / Level2 / Level3. The larger the number, the higher the sensitivity.
 - » SelfCheck Enable: After touching the square to enable this function, you need to enable Self Check to start the checking process. After checking, there will be an alarm about CT if anything abnormal is detected; please check the CT connection and try self checking again.

G Return	
Meter/CT1 State	CT1 🔻
CT1 Enable 🔽	SelfCheck Enable 🔽
CT1 Direction	Positive v
CT1 Sensitivity	Level1 🔻
Self Check	

- Meter: The Meter/CT port is connected to Meter;
 - » Meter1/2 Direction: Here you can set the direction of Meter1/2 to Positive or Negative connection according to the actual situation.

Return	•
Meter/CT1 State	Meter1 🔻
Meter1 Enable 🗹	
Meter1 Direction	Positive

• None: No meter or CT is connected to the Meter/CT port.



Setting Com-parameters

You can select the baud rate and set the address of the external communication protocol for communicating with external equipment.

- » Ex485 Modbus Baudrate: Default: 9600. Range: 4800, 9600, 19200.
- » Ex485 Modbus Address: Default: 1. Range:1~127

9600
1

Setting Check Parameters

Here you can set whether enabling or disabling the following check parameters: **AI_En** (Active islanding detection) and **ExFanCheck_En** (External fan fault detection).

Check Parameter	
Al_En	
ExFanCheck_En	

Setting Reset

Here you can reset value of Comm Module and Meter1/CT1, Meter2/CT2; clear history record and energy records ; and restore to the factory set.

Return		() Return	
Reset		Reset	
Factory Reset	Set	Reset Meter1/CT1	Set
Clear History Record	Set	Reset Meter2/CT2	Set
Reset Comm Module	Set		
Clear Energy Records	Set		

Setting New password

Here you can reset the advanced password.



Setting EPS Control

Here you can set the battery min. SOC in off-grid (EPS) mode for lithium batteries.

- » **Min SOC**: If the battery SOC falls below this value, the battery will stop discharging. Default: 10%. Range: 10%~25%.
- » **ESC Min SOC**: If the battery SOC reaches this value, the battery can restart to discharge. Default: 20%. Range: 15%~100%.

Return			
EPS Control			
Min SOC	10%		
ESC Min SOC	20%		

10.9 History Errors

Displaying path: <a>>History Errors

After entering the **History Errors** interface, the data of history errors will be displayed on the LCD. Information contains error code, error description and the date and time the error happened. Twenty records can be displayed at most.

History Error 1/5			
Code	Info	Time	
7	EPS Overload Fault	24/12/01 10:10:00	
7	EPS Overload Fault	24/12/01 09:10:10	^
87	DC Bus Overvoltage	24/12/01 08:22:12	~
87	DC Bus Overvoltage	24/12/01 00:10:05	

10.10 Parallel Setting

Setting path: ^(a)>Parallel Setting

The series inverters support up to 10 units in the parallel system. The default setting is **Single**, if the inverters are to work in parallel the relative settings must be done. For details of the application of parallel function, please refer to "15.1 Application of Parallel Function".

G Return	
Parallel Settings	
Master/Slave Settings Terminal Resistor	Single

11.1 Introduction of SolaXCloud

SolaXCloud is an intelligent management platform for home energy, which integrates energy efficiency monitoring, device management, data security communication and other integrated capabilities. While managing your home energy device, it helps you optimize the efficiency of electricity consumption and improve the revenue of power generation.

11.2 Operation Guide on SolaXCloud App

11.2.1 Downloading and Installing App

Method 1: Select and scan the QR code below to download the app.



Figure 11-1 QR code for downloading SolaXCloud App

Method 2: Search for **SolaXCloud** iPhone APP Store, Google Play or Appstore of Android phones, and then download the app.

11.2.2 Operations on App

For instructions on related operations, see the online App guide, Wifi connection guide and Setup tutorial video on the SolaXCloud App.

11.3 Operations on SolaXCloud Webpage

Open a browser and enter www.solaxcloud.com to complete registration, login, add site and other related operations according to the guidelines of User guide.

12 Troubleshooting and Maintenance

12.1 Power off

- a. Turn off the system button at the left side of the inverter.
- b. Turn off the DC switch at the left side of the inverter.
- c. Turn off the DC switch between the battery and the inverter and turn off the battery.
- d. Turn off the DC switch between the PV string and the inverter. (If there is any).
- e. Turn off the AC breaker between the inverter and the EPS loads.
- f. Turn off the AC breaker between the inverter and the public grid.

WARNING!

• After the inverter is powered off, there may still be residual electricity and heat which may cause electric shocks and body burns. Please wear personal protective equipment (PPE) and start maintaining the inverter at least five minutes after power off.

12.2 Troubleshooting

This section lists the possible problems with the inverter, and provides information and procedures for identifying and resolving them. In case of any errors, check for the warnings or error messages on the system control panel or App, and then refer to the suggestions below. For further assistance, contact SolaX Customer Service. Please provide the model and SN of the inverter, and be prepared to describe the system installation details.

Error Code	Fault	Diagnosis and Solutions
1	Isolation Fault	Insulation impedance detection failed.Check whether the wire insulation is intact.
2	Meter Fault	Electricity meter has no power. • Check the status of the meter.
4	Grid Freq Mismatch	Frequency configuration mismatch.Check whether the frequency is within the correct range.
6	Arc Fault	Arc fault • Wait for a while to see if it returns to normal.

Table 12-1 Troubleshooting list

Error Code	Fault	Diagnosis and Solutions
7		1.05 times overloadTurn off high-power load.
8	EPS Overload Fault	1.25 times overloadTurn off high-power load.
9	-	1.5 times overloadTurn off high-power load.
10	Overload Self- Lock	Overload self-locking Turn off high-power load, PV, battery and power grid, and restart inverter.
15	Aux Power Volt Fault	Auxiliary power supply abnormal Contact the after-sales personnel.
17		EPS load current exceeds level 1 overcurrent value Turn off high-power load.
18	EPS Overload Fault	EPS load current exceeds level 2 overcurrent value Turn off high-power load.
19	-	EPS load current exceeds level 3 overcurrent value Turn off high-power load.
20	PV1 Reversed	 PV1 reverse connection Turn off PV, battery and power grid, restart inverter, and check the connection status of positive and negative poles of PV1.
21	PV2 Reversed	 PV2 reverse connection Turn off PV, battery and power grid, restart inverter, and check the connection status of positive and negative poles of PV2.
22	PV3 Reversed	 PV3 reverse connection Turn off PV, battery and power grid, restart inverter, and check the connection status of positive and negative poles of PV3.
23	MPPT1 Over Voltage	PV1 Voltage is too high • Check the voltage of PV1.
24	MPPT2 Over Voltage	PV2 Voltage is too high • Check the voltage of PV2
25	MPPT3 Over Voltage	PV3 Voltage is too high • Check the voltage of PV3
26	EPS Overload Fault	EPS load current exceeds level 4 overcurrent value Turn off high-power load.

Error Code	Fault	Diagnosis and Solutions	
40	Bat Type Error	Battery type configuration errorTurn off PV, battery and power grid, restart inverter, and confirm whether the battery type is correct.	
41	Bat Voltage Fault	Battery voltage is too highCheck whether the battery output voltage is within the normal range.	
44	Low Bat SOC	Low battery SOC Please charge the battery in time. 	
45	EPS Overload Fault	EPS load power exceeds the battery power • Turn off high-power load.	
51		The grid voltage exceeds the allowable value 1Check whether the grid voltage is within the normal working range.	
52	Grid Voltage	The grid voltage exceeds the allowable value 2Check whether the grid voltage is within the normal working range.	
53	Fault	The grid voltage is lower than the allowable value 1Check whether the grid voltage is within the normal working range.	
54	-	The grid voltage is lower than the allowable value 2Check whether the grid voltage is within the normal working range.	
55	Ac10mins Volt Fault	 The abnormal grid overvoltage lasts for 10 minutes Check whether the grid voltage is within the normal working range and restart the inverter when the grid voltage is back to normal. 	
57		Power grid frequency exceeds the allowable value 1.Check whether the grid frequency is within the normal working range.	
58	Grid Frequency	Power grid frequency exceeds the allowable value 2Check whether the grid frequency is within the normal working range.	
59	Fault	The power grid frequency is lower than the allowable value 1.Check whether the grid frequency is within the normal working range.	
60		The power grid frequency is lower than the allowable value 2.Check whether the grid frequency is within the normal working range.	

Error Code	Fault	Diagnosis and Solutions
61	Grid Voltage	The grid voltage exceeds the allowable value 3Check whether the grid voltage is within the normal working range.
62	Fault	The grid voltage is lower than the allowable value 3.Check whether the grid voltage is within the normal working range.
63	Grid Frequency	Power grid frequency exceeds the allowable value 3Check whether the grid frequency is within the normal working range.
64	Fault	The power grid frequency is lower than the allowable value 3Check whether the grid frequency is within the normal working range.
70	BST1 Software OCP	BST1 software overcurrent Please contact the after-sales personnel.
71	BST2 Software OCP	BST2 software overcurrent Please contact the after-sales personnel.
72	BST3 Software BST3 software overcurrent OCP • Please contact the after-sales personnel.	
73		BST1 hardware overcurrent Please contact the after-sales personnel.
74	Tz Protect Fault	BST2 hardware overcurrent • Please contact the after-sales personnel.
75	-	BST3 hardware overcurrent • Please contact the after-sales personnel.
77	Tz Protect Fault	BuckBst hardware overcurrent Wait for a while to see if it returns to normal.
78	BuckBst Software OCP	BuckBst software overcurrent Please contact the after-sales personnel.
79	BuckBst Software OVP	BuckBst software overvoltage Please contact the after-sales personnel.
80	BuckBst Software UVP	BuckBst software undervoltage Please contact the after-sales personnel.
81	 Tz Protect Fault The battery may be short-circuited. Use a multimeter to check whether the battery port is short-circuited. Wait for a while to see if it returns to normal. 	

Error Code	Fault	Diagnosis and Solutions
82	LLC Start Fail	Llc startup failed.Please contact the after-sales personnel.
83	BuckBst Start Fail	BuckBst startup failed.Please contact the after-sales personnel.
85	DC Bus Init Fail	DCBUS initialization detection failed.Turn off PV, battery and power grid, and restart inverter.
86	Tz Protect Fault	DCBUS hardware overvoltagePlease contact the after-sales personnel.
87	DC Bus Overvoltage	DCBUS software overvoltagePlease contact the after-sales personnel.
88	DC Bus Undervoltage	DCBUS software undervoltagePlease contact the after-sales personnel.
92	BuckBst Soft Start Fail	DCBUS BUCKBST soft start failed.Please contact the after-sales personnel.
101	INV Relay Fault	Inverter relay faultPlease contact the after-sales personnel.
104	EPS Overload Fault	Soft start AC voltage failed.Please contact the after-sales personnel.
105	INV Software OCP	Inverter software overcurrentPlease contact the after-sales personnel.
106	EPS Overload Fault	Inverter hardware half-wave overcurrentPlease contact the after-sales personnel.
107	EPS Overload Fault	Inverter hardware overcurrentPlease contact the after-sales personnel.
108	DCI OCP Fault	During on-grid operation, DC component of the inverter exceeds the permissible value. • Contact SolaX for help.
109	DCV OVP Fault	During off-grid operation, DC component of the inverter exceeds the permissible value. • Contact SolaX for help.
110	EPS Overload Fault	EPS overload caused inverter soft-start AC voltage failure. • Turn off high-power load.
111	CT/Meter Check Fault	CT faultWait for a while to see if it returns to normal. Check whether CT works properly.
112	GFCI Fault	GFCI fault • Wait for a while to see if it returns to normal.
4		

Error Code	Fault	Diagnosis and Solutions
113	INV Frequent OCP	Inverter frequent overcurrent alarmWait for a while to see if it returns to normal. Check whether the inverter current works in the normal range.
114	INV DM OCP	Inverter overcurrent faultWait for a while to see if it returns to normal.
116	Gen Voltage PLL Fail	The inverter failed to phase lock the generatorWait for a while to see if it returns to normal.
117	Gen Overload	1.5 times overload of the generatorTurn off high-power load.
130	INV Overheat	 Inverter over temperature fault Check whether the fan works normally. If not, shutdown for inspection. If yes, wait for a while and restart when it is back to normal.
131	PV Overheat	PV over temperature faultCheck whether the fan works normally.
132	LLC Overheat	LLC over temperature fault Check whether the fan works normally.
133	High Ambient Temp	Over temperature fault Check whether the fan works normally.
134	Bat Plate Hot (+)	Battery positive copper plate over temperature faultCheck whether the battery power cables can stand the maximum battery current.Check whether the battery cables are connected correctly and whether the screws are tightened.
135	Bat Plate Hot (-)	 Battery negative copper plate over temperature fault Check whether the battery power cables can stand the maximum battery current. Check whether the battery cables are connected correctly and whether the screws are tightened.
140	Type Model Error	 Model configuration error Turn off PV, battery and power grid, and restart inverter. Check whether the inverter model is configured correctly.
145	Para Slave Fault	Slave inverter fault in parallel connection modeCheck the error information on the slave inverter and handle the error correspondingly
146	Para CAN Fault	CAN communication lost in parallel connection modeCheck whether the CAN communication cables between the master and the slaves are correctly connected.Replace the communication cables.

Error Code	Fault	Diagnosis and Solutions
147	Para Sync Fault	 The master and slave inverters failed to synchronize when starting and during operation Check whether the PV, Grid, and battery connections of the master and slave inverters are consistent. If not, reconnect and make sure they are consistent. If yes, wait for fault recovery and automatic restart.
150	Cell Overvoltage	Overvoltage fault of cell.Wait for fault recovery, restart the battery and contact after-sales personnel.
151	Cell Undervoltage	Undervoltage fault of cell. • Recharge the battery.
152	Hight Cell Vol Diff	Excessive voltage difference fault of cell.Ensure that the battery works in the normal voltage range.
153	HVB Overvoltage	Overvoltage fault of total voltage.Wait for fault recovery, restart the battery and contact after-sales personnel.
154	HVB Undervoltage	Undervoltage fault of total voltage.Recharge the battery.
155	Overtemp Fault	High temperature fault.Stop using the battery and wait for the temperature to recover.
156	Self-check Fault	Self-test fault.Check the battery failure and contact the after-sales personnel.
157	Main Relay Stuck(+)	Main positive relay sticking fault. • Please contact the after-sales personnel.
158	Main Relay Open(+)	Main positive relay open circuit fault.Please contact the after-sales personnel.
159	Main Relay Stuck(-)	Main negative relay sticking fault. Please contact the after-sales personnel.
160	Main Relay Open(-)	Main negative relay open circuit fault. • Please contact the after-sales personnel.
161	Precharge Fail	Pre-charge failure fault.Reset the battery. If this fault is reported many times, please contact after-sales personnel.
162	Cell Sample Fault	Cell sampling fault. • Please contact the after-sales personnel.

Error Code	Fault	Diagnosis and Solutions
163	Temp Sample Fault	Temperature sampling fault.Please contact the after-sales personnel.
164	System Fault	System fault. • Please contact the after-sales personnel.
165	Dischrg Overcurrent	 Over-discharge current fault. Stop using the battery and wait for it to recover or restart the battery. If this fault is reported many times, please contact the after-sales personnel
166	Chrg Overcurrent	Over-charge current fault.Ensure that the battery works in the normal voltage range.
167	AFE Comm Fault	AFE communication fault.Please contact the after-sales personnel.
168	INV Comm Fault	 External network communication fault. Check the communication line between the battery and the inverter. If this fault still occurs after reinserting the line, please contact the after-sales personnel.
169	Mid Comm Fault	 Intermediate network communication fault. Check the communication line between the batteries. If this fault still occurs after reinserting the line, please contact the after-sales personnel.
170	Voltage Sensor Fault	Voltage sensor fault.Please contact the after-sales personnel.
171	ID Duplicate	 ID duplication fault. Check if the system connections are correct and follow the initial installation steps to perform the startup operation again.
172	Low Temp Fault	Low temperature fault.Wait for fault recovery, restart the battery and contact after-sales personnel.
173	Current Sensor Fault	Current sensor fault. • Please contact the after-sales personnel.
174	Power Line Open	Power line open circuit fault.Check whether the power line is connected properly and restart the battery.
175	Flash Error	Flash fault. • Please contact the after-sales personnel.
176	AFE Protect Fault	AFE self-protection fault.Please contact the after-sales personnel.

Error Code	Fault	Diagnosis and Solutions
177	Charge Request Fault	Charging request fault.Check if the inverter is correctly supplying power to the battery.
178	Insulation Fault	Insulation fault.Please contact the after-sales personnel.
200	Bat Volt Out Limit	Battery voltage overrun Ensure that the battery works in the normal voltage range.
201	PV Volt Out Limit	Battery voltage overrun Ensure that PV works in the normal voltage range.
202	Low Grid Bat SOC	Low soc of grid-connected battery Stop discharging and start charging.
203	Low EPS Bat SOC	Low soc of off-grid battery • Stop discharging and start charging.
204	INV Power De- rate	Inverter power deratingEnsure that the inverter power is within the normal range.
205	Bat Chrg De-rate	Battery charging power deratingEnsure that the battery charging power is within the normal range.
206	Bat Dischrg De- rate	Battery discharge power deratingEnsure that the battery discharge power is within the normal range.
207	Bat Float Charge	Battery floating charge • Check battery voltage.
208	Bat Recharge	Battery recharge Check the battery voltage and replenish the power in time.
209	Bat Power Config	Battery power configuration modeMake sure that the battery works correctly.
210	Boost CV Mode	BST constant voltage source mode.BST operates in constant voltage source mode.
211	PV De-rate, Inv Limit	Inverter power limitEnsure that the inverter output power is within the normal range.
212	PV De-rate, Rev Flow Alarm	Anti-reflux. • Ensure that it is in an anti-reflux state.
213	PV De-rate, Chrg Limit	Charging power limit. • Ensure that the charging power is within the normal range.

Error Code	Fault	Diagnosis and Solutions
214	PV De-rate, Curr Limit	Current limiting Ensure that the current works within the normal range.
215	Inter Fan Fault	Internal fan failed. • Check whether there is any foreign matter inside the fan.
240	FAN1Fault	External fan1 failure Please check if the external fan is damaged or blocked.
241	FAN2Fault	External fan2 failure Please check if the external fan is damaged or blocked.
242	FAN3Fault	External fan3 failure Please check if the external fan is damaged or blocked.
243	DSP Upgrade Failed	DSP upgrade failurePlease contact after-sales for assistance with software upgrade.
244	ARM Upgrade Failed	ARM upgrade failurePlease contact after-sales for assistance with software upgrade.
245	SMCU Upgrade Failed	SMCU upgrade failurePlease contact after-sales for assistance with software upgrade.
246	Meter1 Lost	Meter lossPlease check if the meter is connected or if the meter communication line works normally.
247	CT1 Lost	CT loss • Please check if the CT is connected.
249	BMS Lost	Communication loss between inverter and battery management system equipment.Please check the connection status between the BMS device and the inverter.
250	Meter2 Lost	Meter lossPlease check if the meter is connected or if the meter communication line works normally.
251	CT2 Lost	CT loss • Please check if the CT is connected.

Error Code Fault Diagnosis and Solutions		Diagnosis and Solutions
/	Screen not on	 Check if the inverter correctly and normally connected to PV, battery or grid. Contact SolaX for help if the inverter is connected correctly.
/	Abnormal sound on fan	Check if there is foreign objects stuck in the fan.Contact SolaX for help.
/	Screen on but no content display	Contact SolaX for help.
/	No readings after CT connection	 Check if CT is correctly clipped on the L wire Check if the arrow on the CT points at Grid. Contact SolaX for help if it can not return to normal.
/	No readings on Load (on App or Web)	 Check if the load is connected correctly. Check if the power of load on the LCD screen displays normally. Check if the monitoring module works normally. Contact SolaX for help if it can not return to normal.
/	No readings on Grid (on App or Web)	 Check if the grid connection is normal. Check if the grid parameter on the LCD screen displays normally. Check if the monitoring module works normally. Contact SolaX for help if it can not return to normal.
/	No readings on battery (on App or Web)	 Check if the battery is connected correctly. Check if the battery parameter on the LCD screen displays normally. Check if the monitoring module works normally. Contact SolaX for help if it can not return to normal.
/	No Feedin data (on App or Web)w	 Check if the meter/CT is connected correctly. Check if the meter/CT parameter on the LCD screen displays normally. Check if the monitoring module works normally. Contact SolaX for help if it can not return to normal.
/	No data on App or Web	Check if the monitoring module works normally.Contact SolaX for help.

Error Code	Fault	Diagnosis and Solutions	
/	No display on meter after power on	 If the meter connection is abnormal, reconnect them according to the wiring diagrams. Wait for the grid voltage to restore. Contact SolaX for help if it can not return to normal. 	
/	Abnormal electrical data on meter	 If the wiring is incorrect, reconnect them based on the wiring diagrams. Set the voltage and current ratio according to the setting steps of meter user manual. Contact SolaX for help if it can not return to normal. 	

12.3 Maintenance

Regular maintenance is required for the inverter. Please check and maintain the following items based on the instructions below to ensure the optimal performance of the inverter. For inverters working in inferior conditions, more frequent maintenance is required. Please keep maintenance records.

🕂 WARNING!

- Only qualified person can perform the maintenance for the inverter.
- Only spare parts and accessories authorized by SolaX can be used for maintenance.

12.3.1 Maintenance routines

Table 12-2	Proposal of	Maintenance
------------	-------------	-------------

Item	Check notes	Maintenance interval
Fans	 Check if the fan makes noise or is covered by dust. Clean the fan with a soft and dry cloth or brush, or replace the fan if necessary. 	Every 12 months
Electrical connection	 Ensure that all cables are firmly connected. Check the integrity of the cables, ensuring that there are no scratches on the parts touching the metallic surface. Verify that the sealing caps on idle terminals are not falling off. 	Every 12 months

Item	Check notes	Maintenance interval
Grounding reliability	• Check if the grounding cables are firmly connected to the grounding terminals. Use a ground resistance tester to test the grounding resistance from the inverter enclosure to the PE bar in the power distribution box.	Every 12 months
Heat sink	Check if there are foreign objects in the heat sink.	Every 12 months
Dongle	Check whether the dongle is securely connected.	From time to time
Indicators	Check if the indicators of the inverter are in normal state.Check if the display of the inverter is normal.	From time to time
General status of inverter	 Check if there is any damage on the inverter. Check if there is any abnormal sound when the inverter is running. 	Every 6 months

12.3.2 Upgrading Firmware

WARNING!

- Make sure that the type and format of the firmware file are correct. Do not modify the file name. Otherwise, the inverter may not work properly.
- Do not modify the folder name and file path where the firmware files are located, as this may cause the upgrade to fail.

WARNING!

• Before upgrading, ensure that the PV input voltage is higher than 180 V (preferably on sunny day), or that the battery SOC is higher than 20%, or the battery input voltage is higher than 180 V. Failure to meet one of these conditions may result in upgrade process failure.

Upgrade preparation

- Prepare a USB drive (USB 2.0/3.0, ≤32 GB, FAT 16/32).
- Check for the current firmware version of the inverter.
- Contact our service support for the update firmware files, and save them to the root directory of the USB drive.

- » X1LiteLV_8_12kW_Vxxx.xx.bin
- » X1LiteLV_8_12kW_lap.txt

Upgrade steps

- a. Plug the U disk into the upgrading port below: If the Dongle is connected to the port, please remove the dongle first.
- b. After the U disk is plugged in, the system will start upgrading, and the three indicator lights and the breathing light will flash in turns. (Operating indicator: green; battery indicator: blue; Error indicator: Red). Wait approximately 4-5 minutes.
- c. After successfully upgraded, the breathing light turns green and the buzzer sounds for one second, and the three indicator lights on the LCD will be a constant state. If the breathing light turns red, it means that the upgrade has failed. If the upgrade fails, please contact our after-sales support.




Figure 12-1 Plug in the U disk

NOTICE!

• The USB disk can be plugged in when the inverter is in normal status.

13 Decommissioning

13.1 Disassembling the Inverter

\Lambda warning!

- Strictly follow the steps below to disassemble the inverter.
- Only use the dedicated removal tool to disassemble the AC connector, PV connector, battery connector and communication connector.
- **Step 1:** Turn off the system by **ON/OFF** on LCD screen.
- Step 2: Disconnect the external breakers of the inverter.
- Step 3: Turn off the system button and the DC switch at the left side of the inverter.
- Step 4: Turn off the battery switch / button / breaker (if any). (See documents of battery)
- **Step 5:** Disconnect the PV connector: Insert the disassemble tool for PV terminal into the notch of PV connector and slightly pull out the connector.




Figure 13-1 Disassembling the PV connector

- **Step 6:** Slightly pull out the dongle module.
- **Step 7:** Disconnect the battery connectors: remove the M8 screws and loosen the swivel nuts, and slightly pull the connectors. (Torque: 15±1 N·m)




Figure 13-2 Removing the battery connector

- **Step 8:** Disconnect EPS, GEN and GRID connector: remove the M6 screws and loosen the swivel nuts, and slightly pull the connectors.
- Step 9: Disconnect the COM connector: loosen the swivel nut of the COM connector and remove the RJ45 terminals of Meter/CT_1, Meter/CT_2, D1/COM, DO, BMS, DRM, PAR_1 and PAR_2.
- Step 10: Put the original terminal caps on the terminals.
- **Step 11:** Unscrew the grounding screw and remove the grounding cable.
- **Step 12:** Unscrew the M4 screw on the sides of inverter and vertically lift up the inverter to dismantle the inverter. (Torque: 1.5±0.1 N·m)




Figure 13-3 Unscrewing the M4 screws

Step 13: Unscrew the screws for fastening the wall mounting bracket and remove the wall mounting bracket if needed.

13.2 Packing the Inverter

• Use the original packaging materials if available.




Figure 13-4 Packing the inverter

- If the original packing material is not available, use the packing material which meets the following requirements:
 - » Suitable for the weight and dimension of product
 - » Convenient for transportation
 - » Can be sealed with adhesive tape

13.3 Disposing of the Inverter

Properly dispose of the inverter and accessories in accordance with local regulations on the disposal of electronic waste.

14 Technical Data

DC input

Model	X1-Lite-8K-LV	X1-Lite-10K-LV	X1-Lite-12K-LV
Max. recommended PV power [W]	16000	20000	24000
Max PV voltage [d.c. V]		600	
Nominal DC operating voltage [d.c. V]		360	
MPPT voltage range [d.c. V]		50-550	
MPPT full power voltage range [d.c. V]	180-500	200-500	180-500
Max. PV curent [d.c. A] ¹	32/32	32/32	32/32/32
Isc PV array short circuit [d.c. A]	40/40	40/40	40/40/40
Start output voltage [d.c. V]	110	110	110
Max. inverter backfeed current to the array [d.c. V]		0	
No. of MPPT	2	2	3
Strings per MPPT	2/2	2/2	2/2/2
DC disconnection switch		Yes	

* "1" When 1 MPPT has 2 string input, if both strings are connected to PV, the maximum string current of a single string does not exceed 16A. If only one string of PV is connected, the maximum single string current does not exceed 32A.

AC output/ input

X1-Lite-8K-LV	X1-Lite-10K-LV	X1-Lite-12K-LV
8000	10000	12000
8800	11000	13200
	220/230/240	
	50/60	
34.8	43.5	52.2
40	50	60
95 135		35
110 165		55
	0.8 leading - 0.8 lagging	
< 3%		
12650	14950	18400
12650	14950 18400	
	220/230/240	
	50/60	
55 65 80		80
0.8 leading - 0.8 lagging		
	8000 8800 34.8 40 95 110 12650 12650	8000 10000 8800 11000 220/230/240 50/60 34.8 43.5 40 50 95 13 110 16 0.8 leading - 0.8 lagging < 3%

Technical Data

Model	X1-Lite-8K-LV	X1-Lite-10K-LV	X1-Lite-12K-LV
AC output & input			
Max. GEN input / output current [a.c. A]	55	65	80
AC connection		L / N / PE	

Battery

Model	X1-Lite-8K-LV	X1-Lite-10K-LV	X1-Lite-12K-LV
Battery type		Lithium / Lead-Acid	
Battery voltage range [d.c. V]		40-60	
Nominal battery voltage [d.c. V]		48	
Max. charging voltage [d.c. V]		≤60 (Adjustable)	
Max. continuous charge/ discharge current [d.c. A]	190	220	250
Charging strategy for Lithium battery	/ Self-adaption to BMS		
Charging strategy for Lead-Acid battery	tery 3 stages curve		
Temperature sensor Optional			

Efficiency, Safety and Protection

Model	X1-Lite-8K-LV	X1-Lite-10K-LV	X1-Lite-12K-LV
Efficiency			
MPPT efficiency	>99.9%	>99.9%	>99.9%
European efficiency	97.0%	97.0%	97.0%
Maximum efficiency	97.6%	97.6%	97.6%
Battery charge efficiency ²	95.0%	95.0%	95.0%
Battery discharge efficiency ²	94.0%	94.0%	94.0%
Safety and Protection			
Safety		IEC/EN 62109-1/-2	
Grid monitoring	NRS 097-2-1, IEC61727, IEC62116, PEA, MEA, BIS		
DC SPD protection	Integrated		
AC SPD protection		Integrated	
Active anti-islanding method		Frequency Shift	
PV string input reverse polarity protection	Yes		
Insulation resistor detection		Yes	
Residual current monitoring unit		Yes	
Output over current protection		Yes	
Output short protection	Yes		
Output over voltage protection	Yes		
Battery terminal temp protection	Yes		
Surge protection		AC Type II / DC Type II	

* "2" PV to BAT Max. efficiency 96.0%, BAT to AC Max. efficiency 95.0%.

EPS (Off-grid) output

Model	X1-Lite-8K-LV	X1-Lite-10K-LV	X1-Lite-12K-LV
Rated EPS apparent power [VA]	8000	10000	12000
Nominal EPS voltage [a.c. V]		230	
Frequency		50/60	
Rated EPS current [a.c. A]	34.8	43.5	52.2
Peak apparent power [VA, s] ³	16000, 10	20000, 10	24000, 10
Switching time (typical value) [ms]		< 4	
Total harmonic distortion (THDv)			
(linear load)		< 2%	

* "3" Depend on PV and battery capacity.

Generic data

Model	X1-Lite-8K-LV	X1-Lite-10K-LV	X1-Lite-12K-LV
Dimensions (W/H/D) [mm]		462*651*280	
Dimensions of packing (W/H/D) [mm]		595*790*340	
Net weight [kg]	35.3	36.9	38.5
Gross weight * [kg]	40.6	42.4	44
Cooling concept		Smart cooling	
Noise emission (typical) [dB(A)]		< 45	
Storage temperature range [°C]		-25 to +70	
Operating ambient temperature range [°C]	-25 to +60 (derating above +45)		
Humidity [%]	4 to 100 (condensing)		
Altitude [m]	< 3000		
Ingress protection	IP65		
Pollution degree	II(Inside), III(Outside)		
Self consumption (night) [W]	< 10		
Installation mode	Wall bracket		
Inverter topology	Non-isolated for PV Side / HF for Battery Side		
Human machine interfaces	LED+LCD		
Communication interfaces	CAN, RS485, CT, Meter, USB, NTC, WiFi+Lan (optional)		

* The specific gross weight is subject to the actual situation of the whole machine, which may be a little different due to the influence of the external environment.

15.1 **Application of Parallel Function**

Introduction of Parallel Application 15.1.1

The series inverters supports parallel operation in both Grid and EPS modes. It supports up to 10 units in the parallel system. This function will be released in guarter 1 of 2025.

15.1.2 Notice for Parallel Application

- All inverters should be of the same software version. .
- For optimal efficiency, it is recommended that all inverters have the same model, and are connected to batteries of the same model and quantity.
- In parallel system, there are two status: Slave and Master. •


Slave	When one inverter is set as a Master , all other inverters will enter Slave mode after these inverters are set as Slave .
Master	When one inverter is set as a Master , this inverter enters Master mode.

- Master inverter has an absolute lead in the parallel system to control slave inverter's energy management and dispatch control. Any master or slave inverter has some error and stop working, the parallel system will be stop simultaneously.
- Both master and slave modes can be changed and set via the LCD screen while the power is off.
- Overall system will be running according to master inverter's setting parameters, and most setting parameters of slave inverter will be kept but not be cancelled.
- Once slave inverter exits from the system and be running as an independent unit (the network cable is disconnected simultaneously), its all setting will be reactivated
- The parallel system is extremely complex and requires a large number of cables to be connected. Therefore, the cables must be connected in the correct wire sequence. Otherwise, any small mistake can lead to system failure.

Table 15-1 Two status

NOTICE!

- The communication cable length between two parallel inverters should not exceed 2 meters, and the total cable length of all parallel inverters should not exceed 15 meters.
- When multiple inverters are connected in parallel, they can share one battery cluster. For details about the wiring procedures, please refer to the corresponding user manual of the battery.



15.1.3 System Wiring Diagram

Figure 15-1 System wiring diagram

15.1.4 System Wiring Procedure

Power cable wiring-Grid and EPS terminal

- a. Grid terminal of Master and Slave inverter: L connects to L and N connects to N,
- b. EPS terminal of Master and Slave inverter: L connects to L and N connects to N,
- c. All PE cable connects to the same E-BAR nearby.




Figure 15-2 Power cable wiring

Communication cable wiring-COM terminal and COM terminal

- a. Use standard network cables for Master-Slave inverter connection.
- b. Master inverter Parallel-2 connects to Slave 1 inverter Parallel-1.
- c. Slave 1 inverter Parallel-2 connects to Slave 2 inverter Parallel-1.
- d. Meter/CT connects to Meter/CT-1 or Meter/CT-2 terminal of the Master inverter. The following wiring is taken Meter/CT-1 terminal as an example.




Figure 15-3 Communication wiring

15.1.5 Settings for Parallel Connection

Parallel setting

Setting path: <a>Parallel Setting

The series inverters support up to 10 units in the parallel system.

- **Master/Slaver Settings**: You can set the state of inverter to **Single** or Parallel. When parallel, the state of inverter can be set to Master/Slave. Select **Master** for the master inverter and **Slave** 1~9 for the slave inverters.
- **Parallel Numbers**: You can set parallel numbers as 1~10 on the master inverter according to the actual application which include both the master and slaves.
- **Terminal resistor**: Inverters with only one parallel communication line need to enable the **Terminal Resistor**. After enabling the **Terminal Resistor** of the two inverters, the whole parallel system can successfully be connected and realize inter-inverter communication.

Master V

Return		Return
Parallel Settings		Parallel Settings
Master/Slave Settings	Single v	Master/Slave Setting
Terminal Resistor	Single Master Slave1 Slave2 Slave3 Slave4	Parallel Numbers Terminal Resistor

15.2 Application of Generator

15.2.1 Introduction of Generator Application

When utility power supply is unavailable, the system can seamlessly switch to the generator for power supply and collaborate with the energy storage system to ensure the uninterrupted use of the load.

In this case, the generator functions as the power grid to supply power for the load, and the hybrid inverter converts the solar energy to electricity.

15.2.2 Notice for Generator Application

- Note 1: The rated output power of the generator should be greater than the sum
 of the load power and the battery charging power. If there are several inverters in
 parallel, the rated output power of the generator should be greater than the sum
 of the load power and the battery charging power of the inverters.
- Note 2: If the rated output power of the generator is small and cannot meet the requirements of Note 1, the setting value of **Max Power Obtain From Gen** can be changed in the **Menu>Smart Load>Generator>Gen Charge Period** to ensure that the generator power can meet the load and battery charging use at the same time.
- Note 3: The EPS load power cannot be greater than the battery discharge power to prevent the battery power from being unable to meet the EPS load after the generator shuts down and the inverter will report an EPS Overload Fault alarm. If two inverters are paralleled, the EPS load power shall be doubled.

15.2.3 Dry Contact Mode

In this operating mode, users can intelligently control the system by establishing a dry contact connection between the inverter and the generator. It allows for adjustments to multiple parameters so that the system can meet the requirements of different scenarios.

Wiring connection diagram




Figure 15-4 Dry contact wiring diagram

Inverter connection for dry contact mode

- Power cable: Connection terminal GEN connection terminal
- Communication cable: Connection terminal DO of COM communication terminal




Figure 15-5 Connection terminal for generator

Connection pins

Table 15-1 Connection pins for generator

Pin	Assignment	Description	
6	DO1_1		
8	DO1_2	—— For generator connection	

 Connection steps: Please refer to "8.3 EPS, GEN and GRID Connection" & "8.6 COM Communication Connection" for specific wire making and connection.

Inverter settings for dry contact mode

Setting path: <a>Smart Load>Generator

- **Gen Rated Power**: Set the rated power of the generator based on the actual situation. Default: 8.0 kW, range: 0.0~20.0 kW
- Gen Max Run Time: Maximum operating time of the generator. Default: 1000min, range: 3~60000min
- **Gen Cool Time**: The cooling time interval between two operating sections of the generator. Default: 60min, range: 0~1440min

Return			
Smart Load None	Load	🗸 Gen	erator
Gen Rated Power		8.00kW	1/5
Gen Max Run Time		1000min	
Gen Cool Time		60min	~

• Gen Start SOC: When the battery SOC is less than this set value, the generator will start to charge the battery while supply power for the load. Default: 20%, range: 17%~78%

G Return			
Smart Load None	Load	🗸 Gen	erator
Gen Start SOC		20 %	2/5
			^
			~

- Gen Charge Period: The generator will charge the battery during the set period(s). Totally three periods can be set and at least one period (Gen Charge Period 1) should be set. You can decide whether to enable Gen Charge Period 2 and Gen Charge Period 3 by touching to select the square on the right side.
 - » Charge: Set the Start time and End time.

- » Gen Charge Stop SOC: When the battery SOC is more than this set value, the generator will stop charging the battery. Default: 80%, range: 22%~100%
- » Max Power Obtain From Gen: Maximum battery charging power from the generator. You can decide whether to enable this setting by touching to select the square on the right side. Default: 5000 W, range:0~65535 W

Return		Return
Smart Load Load	Generator	Smart Load Vone Load Generator
Gen Charge Period 1 Start	3/5 End	Gen Charge Period 2 Start End
Charge 00 : 00	00:00	Charge 00:00 00:00
Gen Charge Stop SOC	80 %	Gen Charge Stop SOC 80 %
Max Power Obtain From Gen	5000 W	Max Power Obtain From Gen 5000 W

Contact Information

UNITED KINGDOM

Unit C-D Riversdale House, Riversdale Road, Atherstone, CV9 1FA

- +44 (0) 2476 586 998
- service.uk@solaxpower.com

TURKEY C*

Fevzi Çakmak mah. aslım cd. no 88 A Karatay / Konya / Türkiye service.tr@solaxpower.com

K 😳 AUSTRALIA

21 Nicholas Dr, Dandenong South VIC 3175

- +61 1300 476 529
- service@solaxpower.com.au

GERMANY

- Am Tullnaupark 8, 90402 Nürnberg, Germany
- +49 (0) 6142 4091 664
- service.eu@solaxpower.com
- service.dach@solaxpower.com

NETHERLANDS

service.eu@solaxpower.com

service.bnl@solaxpower.com

+31 (0) 8527 37932

SPAIN

+34 9373 79607 🚩 tecnico@solaxpower.com

Twekkeler-Es 15 7547 ST Enschede



3780 Kilroy Airport Way, Suite 200, Long Beach, CA, US 90806 +1 (408) 690 9464

POLAND

WARSAW AL. JANA P. II 27. POST +48 662 430 292 service.pl@solaxpower.com

+39 011 19800998 support@solaxpower.it





BRAZIL

+55 (34) 9667 0319 🚩 info@solaxpower.com

SOUTH AFRICA

service.za@solaxpower.com

info@solaxpower.com

ITALY



SolaX Power Network Technology (Zhejiang) Co., Ltd.

Add.: No. 278, Shizhu Road, Chengnan Sub-district, Tonglu County, Hangzhou, Zhejiang, China E-mail: info@solaxpower.com



Copyright © SolaX Power Network Technology (Zhejiang) Co., Ltd. All rights reserved.